


# JS-MD 3 RES

Aircraft Maintenance Manual Supplement



	<b>Aircraft Maintenance Manual Supplement</b>	Doc. No.: MD11-AMM-00-002
Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>	Issue: 05


<b>Aircraft Maintenance Manual Supplement</b>  <b>JS3 RES</b>  <b>MD11-AMM-00-002</b>
---

**Aircraft Serial No.:** .....

**Registration:** .....

The technical content of this document is approved under the authority of the DOA ref. EASA.21J.603. The airworthiness limitation section is an approved section.


This sailplane is to be maintained in compliance with the information and limitations contained herein.

	<b>Aircraft Maintenance Manual Supplement</b>	Doc. MD11-AMM-00-002 No.:
Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>	Issue: 05

This document is the property of M&D Flugzeugbau GmbH and may not be cited,  
 reproduced, disclosed or distributed in whole or in part without prior written permission of  
 M&D Flugzeugbau GmbH.



*Intentionally left blank*


	<b>Aircraft Maintenance Manual</b>		Doc.	MD11-AMM-00-002
	<b>Supplement</b>		No.:	
Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>	Issue:		05

## 0 GENERAL

This Maintenance Manual has been prepared to provide maintenance personnel with the necessary information to maintain the JS-MD 3 RES System. All the data required to be furnished to the pilot and the maintenance personnel, by the Airworthiness Requirement CS-22, is contained in this manual. Supplementary data is also provided by the sailplane manufacturer.

### 0.1 Record of Revisions


Issue	Revision	Date	Reason for Change
00	00	23.05.2022	Initial Issue
01	00	01.06.2023	Updates for TC
02	00	01.02.2025	Liquid cooling system with reservoir upgrade, editorial changes to improve readability
03	00	18.09.2025	Removal of expansion cylinder, editorial changes to improve readability, update of battery life limit, update to RES door layout
04	00	02.02.2026	RES Reactivation
05	00	17.03.2026	Revision based on LBA feedback

	<b>Aircraft Maintenance Manual</b>		Doc.	MD11-AMM-00-002
	<b>Supplement</b>		No.:	
Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>	Issue:		05

## 0.2 List of effective sections


Section	Issue	Revision	Date	Number of Pages	Reference
0	05	00	17.03.2026	10	
1	05	00	17.03.2026	2	
2	05	00	17.03.2026	6	
3	05	00	17.03.2026	2	
4	05	00	17.03.2026	78	
5	05	00	17.03.2026	8	
6	05	00	17.03.2026	18	
7	05	00	17.03.2026	2	
8	05	00	17.03.2026	12	
9	05	00	17.03.2026	4	
10	05	00	17.03.2026	10	
11	05	00	17.03.2026	2	
12	05	00	17.03.2026	2	
13	05	00	17.03.2026	2	
14	05	00	17.03.2026	2	
A	05	00	17.03.2026	4	
B	05	00	17.03.2026	2	
C	05	00	17.03.2026	2	
D	05	00	17.03.2026	5	




	<b>Aircraft Maintenance Manual</b>		Doc. No.:	MD11-AMM-00-002
	<b>Supplement</b>			
Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>	Issue:	05	

## 0.4 Table of Contents


<b>0</b>	<b>General</b> .....	<b>0-1</b>
0.1	Record of Revisions .....	0-1
0.2	List of effective sections .....	0-2
0.3	Record of Amendments .....	0-3
0.4	Table of Contents .....	0-4
0.5	List of Figures .....	0-7
0.6	List of Tables .....	0-9
0.7	List of Abbreviations .....	0-9
<b>1</b>	<b>General</b> .....	<b>1-1</b>
1.1	Descriptive data .....	1-1
1.2	Technical data .....	1-1
<b>2</b>	<b>Description of systems and components</b> .....	<b>2-1</b>
2.1	Introduction and overview .....	2-1
2.2	RES kinematics overview .....	2-3
2.3	Electrical system overview .....	2-4
<b>3</b>	<b>Airworthiness limitations and inspections</b> .....	<b>3-1</b>
3.1	Airworthiness limitations .....	3-1
<b>4</b>	<b>Maintenance schedule</b> .....	<b>4-1</b>
4.1	Annual inspection .....	4-1
4.2	RES actuator assembly .....	4-3
4.3	RES Pylon .....	4-13
4.4	Propeller .....	4-16
4.5	Electric motor .....	4-20
4.6	RES doors .....	4-23
4.7	Front doors (if fitted) .....	4-32
4.8	Battery latches .....	4-34
4.9	Display and Control Unit (DCU) .....	4-36
4.10	LXNAV Bridge .....	4-37
4.11	Motor controller assembly .....	4-38
4.12	DC-DC converter .....	4-69
4.13	Retraction and Fuses Unit (RFU) .....	4-71
4.14	Insulation Monitoring Device (IMD) .....	4-73
4.15	HV Connectors .....	4-74

	<b>Aircraft Maintenance Manual</b>  <b>Supplement</b>	Doc. No.: MD11-AMM-00-002
Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>	Issue: 05

4.16	Avionic Batteries.....	4-77
4.17	Fire warning system .....	4-78
<b>5</b>	<b>Calibration &amp; setup .....</b>	<b>5-1</b>
5.1	Actuator system setup .....	5-1
5.2	Actuator calibration.....	5-4
5.3	Main door setup.....	5-5
5.4	Motor resolver calibration .....	5-7
5.5	Propeller alignment .....	5-8
<b>6</b>	<b>Wiring loom .....</b>	<b>6-1</b>
6.1	Display And Control Unit (DCU) .....	6-1
6.2	RES Control Board (RCB) .....	6-2
6.3	Retraction And Fuses Unit (RFU).....	6-4
6.4	Actuator.....	6-5
6.5	Left battery connector.....	6-6
6.6	Charger connector.....	6-7
6.7	DC-DC converter.....	6-8
6.8	Right battery connector .....	6-9
6.9	Motor, motor controller and resolvers .....	6-11
6.10	Cooling fans .....	6-12
6.11	Insulation Monitoring Device (IMD).....	6-13
6.12	Avionic batteries .....	6-14
6.13	Ground bus .....	6-15
6.14	Supplementary fire warning system.....	6-16
6.15	LXNAV bridge .....	6-17
6.16	Complete schematic.....	6-19
6.17	Supplementary information and pictures .....	6-21
<b>7</b>	<b>Lubrication .....</b>	<b>7-1</b>
7.1	Introduction .....	7-1
7.2	Lubricants.....	7-1
7.3	Lubrication plan.....	7-1
<b>8</b>	<b>System operation .....</b>	<b>8-1</b>
8.1	Guarded RES master switch .....	8-1
8.2	Display and control unit interface.....	8-2
8.3	Battery selection switch .....	8-2
8.4	Motor Controller Circuit Breaker .....	8-2

	<b>Aircraft Maintenance Manual Supplement</b>	Doc. No.: MD11-AMM-00-002
Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>	Issue: 05

8.5	Operational mode.....	8-3
8.6	Other Information screens.....	8-8
8.7	Warning Caution and Information messages.....	8-10
8.8	Maintenance mode.....	8-11
8.9	Setup menu.....	8-11
8.10	Charge mode.....	8-12
8.11	Fire warning system.....	8-12
<b>9</b>	<b>Software/ Firmware update.....</b>	<b>9-1</b>
9.1	Requirements for firmware updated.....	9-1
9.2	DCU firmware update.....	9-2
9.3	RFU firmware update.....	9-3
9.4	Accessing the motor controller parameters.....	9-4
<b>10</b>	<b>High Voltage batteries.....</b>	<b>10-1</b>
10.1	Overview.....	10-1
10.2	Inspections.....	10-2
10.3	Trailer considerations.....	10-2
10.4	Battery status indicators.....	10-3
10.5	Battery handling.....	10-4
10.6	Installing the HV batteries.....	10-4
10.7	Battery care.....	10-5
10.8	Long term storage.....	10-6
10.9	Charging.....	10-7
<b>11</b>	<b>Placard Booklet.....</b>	<b>11-1</b>
<b>12</b>	<b>Special Tool list.....</b>	<b>12-1</b>
<b>13</b>	<b>Service Bulletins.....</b>	<b>13-1</b>
<b>14</b>	<b>Contact.....</b>	<b>14-1</b>
14.1	Type Certificate Holder.....	14-1
14.2	Manufacturer / Maintenance.....	14-1
<b>APPENDIX A – Annual inspection checklist.....</b>		<b>1</b>
<b>APPENDIX B – General torque specifications.....</b>		<b>1</b>
<b>APPENDIX C – STCs and Minor Change Approvals.....</b>		<b>1</b>
<b>APPENDIX D – LIST OF WARNINGS/CAUTIONS.....</b>		<b>1</b>

	<b>Aircraft Maintenance Manual</b>		Doc. MD11-AMM-00-002
	<b>Supplement</b>		No.:
Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>	Issue:	05

## 0.5 List of Figures

Figure 1-1 JS-MD 3 with RES pylon extended .....	1-2
Figure 2-1 RES System overview.....	2-2
Figure 2-2 Kinematics layout overview .....	2-3
Figure 2-3 Electrical system overview .....	2-5
Figure 2-4 Electrical interaction overview .....	2-7
Figure 4-1 RES Actuator Assembly.....	4-3
Figure 4-2 Actuator assembly .....	4-5
Figure 4-3 Pylon bell crank assembly.....	4-6
Figure 4-4 Pylon bell crank bracket assembly .....	4-9
Figure 4-5 Pylon driver arm assembly .....	4-11
Figure 4-6 Pylon assembly.....	4-14
Figure 4-7 Motor wires routing .....	4-15
Figure 4-8 Propeller assembly .....	4-16
Figure 4-9 Electric motor .....	4-21
Figure 4-10 Doors assembly .....	4-23
Figure 4-11 Main door bell crank assembly.....	4-27
Figure 4-12 Main doors assembly .....	4-30
Figure 4-13 Front doors assembly.....	4-32
Figure 4-14 Battery latches .....	4-34
Figure 4-15 DCU.....	4-36
Figure 4-16 Air-cooled motor controller assembly overview .....	4-39
Figure 4-17 Air-cooled motor controller assembly detailed overview .....	4-39
Figure 4-18 Motor controller assembly top view .....	4-41
Figure 4-19 Motor controller PCBs .....	4-42
Figure 4-20 Cooling fans.....	4-44
Figure 4-21 Motor controller HV wire sequence .....	4-46
Figure 4-22 HV wire .....	4-47
Figure 4-23 Liquid-cooled motor controller overview .....	4-48
Figure 4-24 Glove box and battery removal .....	4-49
Figure 4-25 Liquid-cooled motor controller assembly overview .....	4-51
Figure 4-26 Liquid-cooled motor controller top view .....	4-51
Figure 4-27 Liquid-cooled motor controller assembly oblique and bottom view .....	4-52
Figure 4-28 Cold plate fitment.....	4-54
Figure 4-29 Thermal paste and O-ring positions .....	4-55
Figure 4-30 Thermal paste on bottom of cold plate .....	4-55
Figure 4-31 Box stands fitment .....	4-56
Figure 4-32 Motor controller HV wire sequence .....	4-56
Figure 4-33 Motor controller ground wire mounting point .....	4-57
Figure 4-34 Wiring detail .....	4-57
Figure 4-35 Radiator system installation .....	4-59
Figure 4-36 Water pump reducer and threaded inline fitting .....	4-60
Figure 4-37 Radiator and water pump connections .....	4-62
Figure 4-38 Reservoir assembly .....	4-62
Figure 4-39 Overflow tube location.....	4-63
Figure 4-40 Radiator assembly .....	4-65
Figure 4-41 Radiator assembly .....	4-66
Figure 4-42 DC-DC converter .....	4-70
Figure 4-43 DC-DC Converter and RCB PCB assembly .....	4-70
Figure 4-44 RFU .....	4-71
Figure 4-45 Insulation monitoring device.....	4-73



	<b>Aircraft Maintenance Manual</b>  <b>Supplement</b>	Doc. MD11-AMM-00-002 No.:
Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>	Issue: 05

Figure 4-46 High Voltage Connectors .....	4-74
Figure 4-47 Seatback specification .....	4-77
Figure 4-48 Fire warning system .....	4-78
Figure 4-49 Location of 9 V Battery .....	4-79
Figure 5-1 Fuselage clearance .....	5-1
Figure 5-2 Pylon driver arm extension .....	5-2
Figure 5-3 B9 Bulkhead .....	5-2
Figure 5-4 Main door setup .....	5-5
Figure 6-1 DCU wiring .....	6-1
Figure 6-2 RCB Wiring .....	6-2
Figure 6-3 RFU Wiring .....	6-5
Figure 6-4 Actuator Wiring .....	6-5
Figure 6-5 Left battery connector wiring .....	6-6
Figure 6-6 Charger connector wiring .....	6-7
Figure 6-7 DC-DC Converter .....	6-8
Figure 6-8 Right battery connector wiring .....	6-9
Figure 6-9 Motor, motor controller, and resolvers wiring .....	6-11
Figure 6-10 Cooling Fans wiring .....	6-12
Figure 6-11 IMD Wiring .....	6-13
Figure 6-12 Avionics battery wiring .....	6-14
Figure 6-13 Ground bus wiring .....	6-15
Figure 6-14 Supplementary fire warning system wiring .....	6-16
Figure 6-15 Location of thermal switch and heat-sensitive cable .....	6-17
Figure 6-16 LXNAV bridge .....	6-17
Figure 6-17 LXNAV bridge wiring .....	6-17
Figure 6-18 Interlock and HV wiring .....	6-21
Figure 6-19 Charge connector termination plug .....	6-22
Figure 6-20 Battery connector termination plug .....	6-22
Figure 7-1 Lubrication points .....	7-1
Figure 8-1 Guarded RES master switch .....	8-1
Figure 8-2 DCU Primary Controls .....	8-2
Figure 8-3 Standby screen .....	8-3
Figure 8-4 Extension/retraction screen .....	8-4
Figure 8-5 Extended screen .....	8-5
Figure 8-6 Propulsion screen .....	8-6
Figure 8-7 Battery charging screen .....	8-7
Figure 8-8 Other information screens .....	8-8
Figure 8-9 Message screen .....	8-8
Figure 8-10 System screen .....	8-9
Figure 8-11 Warning screen .....	8-10
Figure 8-12 Service screen .....	8-11
Figure 8-13 Setup screen .....	8-11
Figure 8-14 Fire warning system .....	8-12
Figure 9-1 Adapter installation .....	9-4
Figure 10-1 Battery overview .....	10-1
Figure 10-2 Battery status indicators .....	10-3
Figure 10-3 Dual battery operation .....	10-5
Figure 10-4 Single battery operation .....	10-5
Figure 10-5 Dual battery in aircraft charging .....	10-7
Figure 10-6 Single battery in aircraft charging .....	10-8
Figure 10-7 External dual battery charging .....	10-8
Figure 10-8 External single battery charging .....	10-9


	<b>Aircraft Maintenance Manual</b>		Doc. No.:	MD11-AMM-00-002
	<b>Supplement</b>			
Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>		Issue:	05

## 0.6 List of Tables


Table 1-1 RES Technical Data .....	1-1
Table 2-1 Electrical loads .....	2-8
Table 3-1 Life Limits Durations .....	3-1
Table 4-1 Maintenance Requirement Schedule .....	4-2
Table 4-2 Actuator specifications .....	4-5
Table 4-3 DC-DC converter specifications .....	4-69
Table 4-4 Seatpan battery specification .....	4-78

## 0.7 List of Abbreviations

AMO	-	Approved Maintenance Organisation
CAN	-	Controller Area Network
DCU	-	Display and Control Unit
EGT	-	Exhaust Gas Temperature
HV	-	High Voltage (typically 400V in this configuration)
IMD	-	Insulation Monitoring Device
LE	-	Leading Edge
LiFePO	-	Lithium Ferrite Phosphate
M&D	-	M&D Flugzeugbau GmbH & Co. KG
MCP	-	Maximum continuous power
MOP	-	Means of Propulsion
MP	-	Maximum power
NAA	-	National Aviation Authority
OAT	-	Outside Air Temperature
OEM	-	Original Equipment Manufacturer
PRS	-	Power Rail Supply
RCB	-	RES control box
RFU	-	Retraction and Fuses Unit
RPM	-	Revolutions Per Minute
SOC	-	State of charge
TCDS	-	Type Certificate Data Sheet
TE	-	Trailing Edge
VFR	-	Visual flight rules
VMC	-	Visual meteorological conditions

 MD FLUGZEUGBAU    JONKER SAILPLANES	<b>Aircraft Maintenance Manual Supplement</b>	Doc. No.:	MD11-AMM-00-002
Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>	Issue:	05

*Intentionally left blank*

	<b>Aircraft Maintenance Manual</b>	Doc. No.:	MD11-AMM-00-002
	<b>Supplement</b>		
Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>	Issue:	05

## 1 GENERAL

### 1.1 Descriptive data


The JS-MD 3 RES System is an electric propulsion system used for self take-off or sustained flight when soaring conditions become unfavourable. Propulsion is made possible using a 2-bladed propeller powered by an electric motor mounted on a retractable pylon in the center section of the fuselage.


The normal performance of the sailplane continues when the pylon is retracted.

### 1.2 Technical data

System technical data	
Propulsion system	SOLO Electric Propulsion System 80400
Propeller Type	Technoflug KS-1C-120-R-065-S
Battery type	ELECTRIC BM 384 (96S4P)
Maximum RPM	4350
Max battery power for take-off (2 batteries)	40 kW
Max continuous battery power (2 batteries)	25 kW
Max battery power (1 battery)	25 kW
Max continuous battery power (1 battery)	12.5 kW
Complete system mass – no batteries	~24 kg (53 lbs)
Maximum Motor temperature	120 °C
Maximum Controller temperature	85 °C
Maximum HV Batteries temperature	70 °C


**Table 1-1 RES Technical Data**

	<b>Aircraft Maintenance Manual Supplement</b>	Doc. No.:	MD11-AMM-00-002
Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>	Issue:	05



**Figure 1-1 JS-MD 3 with RES pylon extended**


*Intentionally left blank*


	<b>Aircraft Maintenance Manual Supplement</b>	Doc. No.: MD11-AMM-00-002
Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>	Issue: 05

## 2 DESCRIPTION OF SYSTEMS AND COMPONENTS


### 2.1 Introduction and overview

The RES system can be divided into two main systems, the kinematic system, and the electrical system.

	<b>Aircraft Maintenance Manual Supplement</b>	Doc. No.: MD11-AMM-00-002
Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>	Issue: 05




**Figure 2-1 RES System overview**

	<b>Aircraft Maintenance Manual Supplement</b>	Doc. No.: MD11-AMM-00-002
Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>	Issue: 05

## 2.2 RES kinematics overview

### 2.2.1 Kinematics layout overview

The pylon extension/retraction kinematic system is contained inside the fuselage bay and controls the pylon position as well as the operation of the main doors.




**Figure 2-2 Kinematics layout overview**

This system is comprised of a single pylon, for the mounting of the motor, driven by an electromechanical actuator. The doors open in sequence with the movement of the pylon and are closed when the pylon is fully extended.

### 2.2.2 Kinematics components

The RES system consists of the following kinematic components:


- Actuator assembly
- Pylon Assembly
- Main Doors Assembly
- Battery latches


	<b>Aircraft Maintenance Manual Supplement</b>	Doc. No.: MD11-AMM-00-002
Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>	Issue: 05

## 2.3 Electrical system overview


### 2.3.1 Electrical overview


The electrical system consists of various components, as illustrated in Figure 2-3 for the air-cooled motor controller and Figure 2-4 for the liquid-cooled system:

	<b>Aircraft Maintenance Manual Supplement</b>	Doc. No.: MD11-AMM-00-002
Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>	Issue: 05



**Figure 2-3 Electrical system overview (air-cooled)**

	<b>Aircraft Maintenance Manual</b>		Doc. No.:	MD11-AMM-00-002
	<b>Supplement</b>			
Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>		Issue:	05




**Figure 2-4 Electrical system overview (liquid-cooled)**

### 2.3.2 Electrical components

The electrical system consists of the following electrical components:

- HV Batteries (removable)
- Avionic Batteries (removable)
- Display and control unit (DCU)
- Motor Controller assembly
- Cooling system (Air cooled or liquid cooled)
- RES Control Board (RCB)
- DC-DC converter (400 V - 12 V)
- Retraction and Fuses Unit (RFU)
- Insulation monitoring device (IMD)
- Charging Port (Optional)
- HV Connectors
- Wiring Looms

The electrical components interact with each other as illustrated in Figure 2-5:

	<b>Aircraft Maintenance Manual Supplement</b>	Doc. No.: MD11-AMM-00-002
Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>	Issue: 05





Figure 2-5 Electrical interaction overview

	<b>Aircraft Maintenance Manual</b>		Doc.	MD11-AMM-00-002
	<b>Supplement</b>		No.:	
Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>	Issue:		05

### 2.3.3 Electrical loads

Electrical loads protection required for the system is given in Table 2-1.


Component	Operating Voltage (V)	Peak Current (A)
RES propulsion system	270-400	125
Motor controller	12	4
Motor controller cooling fans	12	8
Actuator	12	11.5
DC-DC converter (400V-14.4V)	12	8

**Table 2-1 Electrical loads**


### 2.3.4 Control system

The pilot controls the system via the Display and Control Unit (DCU) installed on the instrument panel. Data from the DCU is sent to the Retraction and Fuse Unit (RFU) and inverter where the data is processed. Various control inputs include extension/retraction and desired power setting. RPM is regulated by the motor controller by adjusting the AC power supplied to the motor.

**NOTE:** The DCU contains pre-loaded default settings preventing the pilot from operating the system outside of its envelope. RPM and the temperatures (controller, motor, and battery) are restricted within the operational limits by lowering the output power.

 MD FLUGZEUGEALU JONKER SAILPLANES	<b>Aircraft Maintenance Manual Supplement</b>	Doc. No.: MD11-AMM-00-002
Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>	Issue: 05

*Intentionally left blank*

	<b>Aircraft Maintenance Manual</b>		Doc.	MD11-AMM-00-002
	<b>Supplement</b>		No.:	
Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>	Issue:		05


### 3 AIRWORTHINESS LIMITATIONS AND INSPECTIONS

#### 3.1 Airworthiness limitations


Table 3-1 lists the life limits that should not be exceeded. When these limits have been reached, the affected component must be returned to the manufacturer or an approved maintenance organisation so that the required maintenance activities or inspections can be performed.

Component / System	RES system life limits	
	Manufacturer	NOTES
Propeller	TECHNOFLUG Leichtflugzeugbau	Refer to manufacturer's maintenance schedule
Batteries	SOLO Aircraft Engines	Refer to manufacturer's maintenance schedule
Motor	SOLO Aircraft Engines	Refer to manufacturer's maintenance schedule

**Table 3-1 Life Limits Durations**

	<b>Aircraft Maintenance Manual Supplement</b>	Doc. No.: MD11-AMM-00-002
Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>	Issue: 05

*Intentionally left blank*

	<b>Aircraft Maintenance Manual Supplement</b>	Doc. No.: MD11-AMM-00-002
Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>	Issue: 05

## 4 MAINTENANCE SCHEDULE

**WARNING:** Before performing any maintenance, the HV batteries must be removed.

**WARNING:** Only OEM and authorised organisations are allowed to maintain high-voltage components.

**WARNING:** Either the propeller or the HV batteries must be removed unless the aircraft is located in an authorised and secured propeller test area designed for engine run-ups.

### 4.1 Annual inspection


A mandatory annual inspection is required for issuing the Airworthiness Review Certificate.

**NOTE:** Some regulating authorities require one-year or 100-hour interval inspections.

#### General inspection guidelines

- Inspect all bolted connections and locking devices, i.e. locknuts, split pins, etc.
- Check all metal parts for adequate greasing and rust prevention.
- Check for signs of damage


Use the inspection checklist given in APPENDIX A – Annual inspection checklist to perform the annual inspection. The maintenance requirements schedule is illustrated in Table 4-1.

	<b>Aircraft Maintenance Manual</b> <b>Supplement</b>	Doc. MD11-AMM-00-002
	Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>

Who may perform the Maintenance	Maintenance interval
OWNER	Every 2 years
AMO	Every 300 engine hours or 15 years
AMO	Every 100 engine hours or annually
OWNER	Every 25 hours
OWNER	Every 5 years


Maintenance requirements					
Motor overhaul by manufacturer (Refer to Solo 80400 manual)				X	
Controller cooling system fan(s) replacement (Refer to section 5)				X	
Controller check i.a.w. Solo 80400 manual				X	
Clean cooling fins & controller fans (air-cooled system)					X
Clean radiator core with compressed air in the opposite direction of airflow (liquid-cooled system)					X
Replace thermal paste and O-ring (liquid-cooled system)				X	
Replace coolant (liquid-cooled system)	X				
System Annual Inspection (Refer to APPENDIX A – Annual inspection checklist)			X		
Propeller & functional check (Refer to section 4.4.2 and Solo 80400 manual)		X			
Check reservoir for leakage			X		
Propeller overhaul by manufacturer				X	
Replace fire warning 9 V battery (Refer to section 4.16)			X		

**Table 4-1 Maintenance Requirement Schedule**

	<b>Aircraft Maintenance Manual</b>		Doc. No.:	MD11-AMM-00-002
	<b>Supplement</b>			
Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>	Issue:	05	


## 4.2 RES actuator assembly

The actuator assembly is responsible for the retraction and extension of the pylon. It consists of the following components, as illustrated in Figure 4-1.



No	Description	No	Description
1	Actuator	2	Pylon bell crank
3	Pylon bell crank bracket	4	Pylon driver arm
5	Pylon assembly		


**Figure 4-1 RES Actuator Assembly**

	<b>Aircraft Maintenance Manual</b> <b>Supplement</b>	Doc. MD11-AMM-00-002
	Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>


#### 4.2.1 Actuator

The assembly is driven by a 12 V actuator which is controlled by the DCU and RFU. The actuator has built-in limit switches and a hall effect sensor to monitor the extension and retraction of the pylon.

##### 4.2.1.1 Overview



No	Description	No	Description
1	Actuator bracket bolt	2	Actuator bracket
3	Actuator bolt	4	Wheelbox actuator cover blackplate
5	Actuator	6	Bell crank bolt
7	Door close cable	8	Wheelbox actuator cover plate
9	Wheelbox actuator back plate	10	Wheelbox cover plate bolts
11	Actuator front	12	Sub assembly

	<b>Aircraft Maintenance Manual</b>		Doc.	MD11-AMM-00-002
	<b>Supplement</b>		No.:	
Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>	Issue:		05

**Figure 4-2 Actuator assembly**

#### 4.2.1.2 Specification

**Table 4-2 Actuator specifications**


Parameter	Value
Part Number	107 09 230 00
Input voltage	12V
Maximum current	11.6A

#### 4.2.1.3 Removal procedure of Actuator

1. Extend the pylon to a position slightly below the extended position.
2. Switch off the RES master switch.
3. Remove the main doors.
4. Support the pylon slightly below the extended position.
5. Remove **Bell crank bolt (6)**.
6. Remove the **Actuator front (11)** from the actuator by unscrewing it.
7. Disconnect the actuator wiring.
8. Loosen the six **Wheelbox cover plate bolts (10)**.
9. The actuator **Sub assembly (12)** can now be removed from the fuselage through the wheelbox. The hole inside the wheelbox is big enough for the actuator to pass through.
10. The **Actuator (5)** can be removed from the **Wheelbox actuator cover plate (8)** by loosening the two **Actuator bracket bolts (1)**.

#### 4.2.1.4 Installation procedure of Actuator

1. Fasten the **Actuator (5)** to the **Wheelbox actuator cover plate (8)** by fastening the two **Actuator bracket bolts (1)**.
2. Install the actuator **Sub assembly (12)** into the aircraft by inserting it through the hole in the wheelbox.
3. Fasten the six **Wheelbox cover plate bolts (10)**.
4. Connect the actuator wiring.
5. Fasten the **Actuator front (11)** to the actuator.
6. Install and fasten the **Bell crank bolt (6)**.
7. Remove the pylon support.
8. Install the main doors.


	<b>Aircraft Maintenance Manual</b>		Doc. No.:	MD11-AMM-00-002
	<b>Supplement</b>		No.:	
Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>	Issue:	05	

**NOTE:** The actuator system and main door setup must be done again to ensure the kinematic system is working correctly. Refer to the **Calibration & setup** section.

#### 4.2.2 Pylon bell crank

The pylon bell crank is connected to the actuator and pylon driver arm. The pylon bell crank is held in place by the pylon bell crank bracket as illustrated in Figure 4-3.

##### 4.2.2.1 Overview





No	Description	No	Description
1	Pylon bell crank bracket bolt	2	Actuator bolt
3	Pylon bell crank	4	Pylon driver arm bolt

**Figure 4-3 Pylon bell crank assembly**

##### 4.2.2.2 Removal procedure of Pylon bell crank

1. Extend the pylon to a position slightly below the extended position.
2. Switch off the RES master switch.
3. Remove the main doors.
4. Support the pylon slightly below the extended position.
5. Remove the **Actuator bolt (2)**.
6. Remove the **Pylon driver arm bolt (4)**.
7. Remove the **Pylon bell crank bracket bolt (1)**.


	<b>Aircraft Maintenance Manual Supplement</b>	Doc. No.: MD11-AMM-00-002
Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>	Issue: 05

	<b>Aircraft Maintenance Manual Supplement</b>	Doc. No.: MD11-AMM-00-002
Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>	Issue: 05

#### 4.2.2.3 Installation procedure of Pylon bell crank

1. Install the **Pylon bell crank bracket bolt (1)**.
2. Install the **Pylon driver arm bolt (4)**.
3. Install the **Actuator bolt (2)**.
4. Remove the pylon support.
5. Install the main doors.


**NOTE:** The actuator system and main door setup must be done again to ensure the kinematic system is working correctly. Refer to the **Calibration & setup** section.

	<b>Aircraft Maintenance Manual</b>		Doc. No.:	MD11-AMM-00-002
	<b>Supplement</b>			
Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>		Issue:	05

### 4.2.3 Pylon bell crank bracket

The pylon bell crank bracket is located at the bottom of the rear fuselage compartment and fastened to the bottom of the fuselage using four fastening nuts as illustrated in Figure 4-4.

#### 4.2.3.1 Overview




No	Description	No	Description
1	Pylon bell crank bracket bolt	2	Pylon bell crank
3	Door close cable	4	Pylon bell crank bracket bolts
5	Pylon bell crank bracket		

**Figure 4-4 Pylon bell crank bracket assembly**

#### 4.2.3.2 Removal procedure of Pylon bell crank bracket


1. Extend the pylon to a position slightly below the extended position.
2. Switch off the RES master switch.
3. Remove the main doors.
4. Support the pylon slightly below the extended position.
5. Cut the **Door close cable (3)**.
6. Remove the **Pylon bell crank bracket bolt (1)**.
7. Remove the four **Pylon bell crank bracket bolts (4)**.
8. Remove the **Pylon bell crank bracket (5)**.

	<b>Aircraft Maintenance Manual Supplement</b>	Doc. No.: MD11-AMM-00-002
Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>	Issue: 05

#### 4.2.3.3 Installation procedure of Pylon bell crank bracket

1. Install the **Pylon bell crank bracket (5)** by fastening the four **Pylon bell crank bracket bolts (4)**.
2. Install the **Pylon bell crank bracket bolt (1)**.
3. Install a new **Door close cable (3)**.
4. Remove the pylon support.
5. Install the main doors.


**NOTE:** The actuator system and main door setup must be done again to ensure the kinematic system is working correctly. Refer to the **Calibration & setup** section.

	<b>Aircraft Maintenance Manual</b> <b>Supplement</b>	Doc. No.:	MD11-AMM-00-002
	Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>	Issue:

#### 4.2.4 Pylon driver arm


The pylon driver arm is connected to the pylon and pylon bell crank, as illustrated in Figure 4-5.

##### 4.2.4.1 Overview



No	Description	No	Description
1	Pylon bell crank	2	Pylon driver arm bush
3	Pylon driver arm	4	Pylon driver arm lock
5	Pylon driver arm nut	6	Pylon driver arm bolt
7	Rod end	8	Pylon bolt
9	Pylon	10	Pylon driver arm lock bolt

**Figure 4-5 Pylon driver arm assembly**

	<b>Aircraft Maintenance Manual</b>  <b>Supplement</b>	Doc. No.: MD11-AMM-00-002
Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>	Issue: 05


#### 4.2.4.2 Removal procedure of Pylon driver arm

1. Extend the pylon to a position slightly below the extended position.
2. Switch off the RES master switch.
3. Remove the main doors.
4. Support the pylon slightly below the extended position.
5. Disconnect the Pylon driver arm (3) from the Pylon (9) by unfastening the Pylon bolt (8).
6. Loosen the Pylon driver arm bolt (6) and nut (5) to free the Pylon driver arm (3).
7. The Pylon driver arm lock (4) can be replaced by loosening the Pylon driver arm lock bolt (10).

#### 4.2.4.3 Installation procedure of Pylon driver arm

1. Insert the **Pylon driver arm lock (4)** and fasten it into place using the **Pylon driver arm lock bolt (10)**.
2. Fasten the **Pylon driver arm bolt (6)** and **Nut (5)** to install the **Pylon driver arm (3)**.
3. Connect the **Pylon driver arm (3)** to the **Pylon (9)** by fastening the **Pylon bolt (8)**.
4. Remove the pylon support.
5. Install the main doors.


**NOTE:** The actuator system and main door setup must be done again to ensure the kinematic system is working correctly. Refer to the **Calibration & setup** section.


	<b>Aircraft Maintenance Manual</b> <b>Supplement</b>	Doc. No.: MD11-AMM-00-002
Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>	Issue: 05

### 4.3 RES Pylon

The pylon is the main structural component connecting the motor to the fuselage of the aircraft. The pylon is a dynamic component that is extended and retracted into the fuselage of the aircraft by the actuator assembly.

#### 4.3.1 Overview



	<b>Aircraft Maintenance Manual</b>		Doc. MD11-AMM-00-002
	<b>Supplement</b>		No.:
Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>	Issue: 05	

No	Description	No	Description
1	EMRAX 208 Electric motor	2	Locking wire
3	Propeller bolt	4	Pylon cover
5	Propeller ring	6	Pylon
7	Propeller	8	Pylon nut
9	Pylon driver bush	10	Washer
11	Pylon driver bolt	12	Pylon base bracket bolt
13	Pylon base bracket	14	Pylon Sleeve nut
15	Pylon base bush	16	Pylon sleeve
17	Pylon Sleeve bolt		

**Figure 4-6 Pylon assembly**


#### 4.3.2 Maintenance & Checks of RES Pylon

- Before any run-up of the system be sure to check the pylon for any cracks, chips, or any visible signs of stress or delamination.
- The pylon can be cleaned of any bugs and dirt after every flight using a damp cloth.
- If the pylon has any visible damage ensure that is inspected and repaired by a qualified maintenance organisation, to prevent further damage or failure.

#### 4.3.3 Removal procedure of RES Pylon

1. Extend the pylon to a position slightly below the extended position to ensure the main doors are fully open.
2. Switch off the RES master switch.
3. Disconnect the motor wires (HV, resolver, and ground wires). Refer to the 4.5 Electric motor section.
4. Disconnect the pylon driver arm by loosening the **Pylon driver bolt (11)**
5. Detach the **Pylon (6)** by loosening the four **Pylon base bracket bolts (12)**
6. Remove the **Pylon base brackets (13)**
7. Remove the **Pylon (6)** from the fuselage.
8. The four **Pylon base bushes (15)** can now be removed.
9. The **Pylon sleeve (16)** can be removed by loosening the **Pylon Sleeve bolt (17)** and nut **(14)**.

**CAUTION:** Be careful not to damage the various motor wires when removing the pylon.


	<b>Aircraft Maintenance Manual</b> <b>Supplement</b>	Doc. No.: MD11-AMM-00-002
	Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>

**NOTE:** It is advisable to remove the motor as it makes the handling of the pylon easier.


#### 4.3.4 Installation procedure of RES Pylon

1. Route the various motor wires through the pylon (refer to the Electric motor section).
2. Fasten the **Pylon sleeve (16)** using the **Pylon Sleeve bolt (17)** and **Pylon sleeve nut (14)**.
3. Place the four **Pylon base bushes (15)** over the **pylon sleeve (16)**.
4. Place the **Pylon (6)** in the correct position against the **Pylon base bushes (15)**.
5. Place the **Pylon base brackets (13)** in the correct position against the **Pylon base bushes (15)**.
6. Fasten the pylon using the four **Pylon base bracket bolts (12)**.
7. Attach the pylon driver arm to the pylon using the **Pylon driver bolt (11)**.
8. Connect the various motor wires (refer to the Electric motor section)

**NOTE:** The motor wires should pass the pylon sleeve on the front side of the pylon (shown in Figure 4-7) for a neater installation.




**Figure 4-7 Motor wires routing**

	<b>Aircraft Maintenance Manual</b>	Doc. No.:	MD11-AMM-00-002
	<b>Supplement</b>		
Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>	Issue:	05

## 4.4 Propeller

The propeller is fastened directly to the EMRAX 208 Electric motor by six fastening bolts, as illustrated Figure 4-8.

### 4.4.1 Overview



No	Description	No	Description
1	Propeller - Technoflug KS1	2	Propeller fastening bolts
3	Locking wire (Ø 0.025" Stainless steel)	4	Propeller ring
5	EMRAX 208 HV	6	Pylon


Figure 4-8 Propeller assembly

### 4.4.2 Maintenance & checks of Propeller

#### 4.4.2.1 Checks

- Before any run-up of the propeller be sure to check the propeller for any cracks, chips, or any visible signs of stress or delamination. Verify that the locking wire is still in place and not damaged.
- The propeller can be cleaned of any bugs and dirt after every flight using a damp cloth or with water and car shampoo.

**WARNING:** Avoid using aggressive cleaning agents such as acetone, as they may damage the surface finish.

	<b>Aircraft Maintenance Manual</b>  <b>Supplement</b>	Doc. No.: MD11-AMM-00-002
Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>	Issue: 05

#### 4.4.2.2 Inspections

After 25 hours of operation the operator or AMO must inspect the propeller after washing it thoroughly for any cracks and ruptures. Chips and cracks could cause the propeller to become unbalanced which will increase vibrations.

The following cracks can be tolerated:

1. Cracks on the surface with a distance greater than 5 mm if they cannot be felt
2. Cracks in cobweb form or with concentric rings if they are smaller than 10 cm
3. Bumps due to small stones smaller than 5 mm
4. Swelling smaller than 10 mm
5. Cracks in the erosion protection at the nose, if smaller than 5 mm
6. Yellowed erosion protection
7. Inspect the locking wires between the screws on the hub to ensure there are no frayed or broken wires


Greater flaws, especially cracks and holes where ends of fibres become visible or cracks in the trailing edge, must be repaired. If there is any doubt, send the propeller to Technoflug for repair.

**WARNING:** The propeller must be statically balanced after repair and before fitment, and it is recommended to verify the vibrations caused by the propeller by having it dynamically balanced. Excessive vibrations could cause damage or destroy the propeller and other components.

#### 4.4.3 Removal process of Propeller

1. Extend the pylon to the extended position.
2. Switch off the RES master switch.
3. Remove the **Locking wire (3)**.
4. Remove the six **Propeller fastening bolts (2)**.
5. Remove the **Propeller (1)** and **Propeller ring (2)**.

**NOTE:** Before removing the propeller, note or mark the relative position of the propeller to the motor. If the relative orientation is changed with the propeller installation, the propeller alignment must be recalibrated (refer to the **Calibration & setup** section).

	<b>Aircraft Maintenance Manual</b>  <b>Supplement</b>	Doc. No.: MD11-AMM-00-002
Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>	Issue: 05

#### 4.4.4 Installation process of Propeller

1. Fit the six **Propeller fastening bolts (2)** through the **Propeller ring (2)** and **Propeller (1)**.
2. Fasten the propeller to the EMRAX 208 HV (5), by fastening the six **Propeller Fastening bolts (2)** [20-25Nm].
3. Use **Locking wire (3)** to lock the six **Propeller fastening bolts (2)** into position by using an appropriate locking wire plier.
4. Verify that the motor assembly rotates freely after propeller installation.


**WARNING:** The propeller must be statically balanced before fitment, and it is recommended to verify the vibrations caused by the propeller by having it dynamically balanced. Excessive vibrations could cause damage or destroy the propeller and other components

**CAUTION:** The orientation of the propeller should be as indicated in the figure above. The Techoflug balancing washer should face forward.

**CAUTION:** Be sure to have the same propeller-motor orientation when installing the propeller as when it was removed, otherwise, the propeller alignment must be recalibrated (Refer to the Calibration & setup section).

**CAUTION:** If the propeller alignment is wrongly set, the propeller could cause damage to the main doors or fuselage.

**CAUTION:** If the wrong bolts are used, they could bottom out, preventing the motor to rotate freely.

	<b>Aircraft Maintenance Manual Supplement</b>	Doc. No.: MD11-AMM-00-002
Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>	Issue: 05

#### 4.4.5 Change of leading-edge protection film/tape of Propeller


The following procedure can be followed if a new protection tape is necessary:

- (M3 Scotch 8562, 25 mm Artikel-Nr. 3856225300)

It is also available from the manufacturer. Do not use other materials.

1. Remove the old leading edge protection tape.
2. Clean the bonding surfaces thoroughly with Acetone.
3. Fix the new tape first directly at the leading edge.
4. Cut the ends to the correct length and round them.
5. Use a hairdryer to fix the tape without wrinkles, then press the tape thoroughly to the surface.


**CAUTION:** Never touch the clean surface.

	<b>Aircraft Maintenance Manual</b>	Doc. No.:	MD11-AMM-00-002
	<b>Supplement</b>		
Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>	Issue:	05


## 4.5 Electric motor

The Emrax 208 HV is located at the top of the pylon and is fastened using 6x M8 bolts. The motor has three High voltage terminals and a tandem motor resolver setup.

### 4.5.1 Overview



No	Description	No	Description
1	EMRAX 208 HV	2	Propellor bolt fastening point
3	Pylon	4	Pylon cover
5	Pylon cover fastening bolts	6	High voltage terminal
7	Resolver plate	8	Motor fastening bolts
9	Resolver wires	10	Resolvers

	<b>Aircraft Maintenance Manual</b>		Doc.	MD11-AMM-00-002
	<b>Supplement</b>		No.:	
Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>	Issue:		05

11	Alignment marks		
----	-----------------	--	--

**Figure 4-9 Electric motor**

#### **4.5.2 Maintenance & checks of Electric motor**


The Emrax 208 motor and controller must be maintained according to the Solo Flugzeugbau Motor Overhaul Manual.

Servicing must be done at maintenance organisations approved to perform the maintenance.

#### **4.5.3 Removal procedure of Electric motor**

1. Extend the pylon to the extended position.
2. Switch off the RES master switch.
3. Remove the **Pylon rear cover (4)**, by loosening the six **Pylon cover fastening bolts (5)**.
4. Disconnect the high voltage wires which are connected to **The high voltage terminals (6)** of the motor.
5. Disconnect the **Resolver wires (9)**.
6. Disconnect the motor ground wire which is held in place by one of the six **Motor fastening bolts (8)**.
7. To free the motor from the pylon, remove the six **Motor fastening bolts (8)**.
8. Remove the motor from the pylon.

**WARNING:** The **Resolver plate (7)** has a specific orientation to the Motor. If this orientation is changed, the calibration of the resolvers will be out. The resolvers must be recalibrated (refer to the **Calibration & setup** section). When the calibration is out, the motor could behave unpredictably and start rotating even if no power is requested by the DCU.


	<b>Aircraft Maintenance Manual</b>  <b>Supplement</b>	Doc. No.: MD11-AMM-00-002
Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>	Issue: 05

#### 4.5.4 Installation procedure of Electric motor

1. Make sure the **Resolver plate (7)** is fitted to the **Emrax 208 HV (1)** motor and in the correct orientation. The **Alignment marks (11)** must align.
2. Fasten five out of the six **Motor fastening bolts (8)**. Do not fasten the motor fastening bolt indicated in Figure 4-8 yet.
3. Fasten the motor ground wire using the remaining **Motor fastening bolt (8)**.
4. Fasten the three high voltage wires to the corresponding **High voltage terminals (6)**. Be sure to match the colour markers on the wires and the terminals.
5. Connect the motor **Resolver wires (9)**.
6. Install the **Pylon rear cover (4)** by fastening the six **Pylon cover fastening bolts (5)**.

**WARNING:** The **Resolver plate (7)** has a specific orientation to the Motor. If this orientation is changed, the calibration of the resolvers will be out. The resolvers must be recalibrated (refer to the **Calibration & setup** section). When the calibration is out, the motor could behave unpredictably and start rotating even if no power is requested by the DCU.

**WARNING:** If the phase wire colors are not connected in the correct sequence, the motor may rotate in the wrong direction or the system may be damaged.


	<b>Aircraft Maintenance Manual</b>		Doc. No.:	MD11-AMM-00-002
	<b>Supplement</b>		No.:	
Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>	Issue:	05	

## 4.6 RES doors

The RES door system is designed as a single configuration based on the main doors. These main doors are actuated via the main door bell crank and provide the required aerodynamic closure during operation. When the pylon is extended, the main doors remain slightly open, which aids cooling.


Optional small front doors (3) may be installed; however, when fitted, they must be secured in accordance with the applicable work instruction. This ensures that they no longer operate independently and do not function as separate, spring-loaded elements within the system.


### 4.6.1 Overview



No	Description	No	Description
1	Main door bell crank	2	Main Doors
3	Front Doors		


**Figure 4-10 Four Doors assembly**

	<b>Aircraft Maintenance Manual</b>		Doc. No.:	MD11-AMM-00-002
	<b>Supplement</b>		No.:	
Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>	Issue:	05	



No	Description	No	Description
1	Main door bell crank	2	Main Doors (optional no cutout)


**Figure 4-11 Two Doors assembly**


	<b>Aircraft Maintenance Manual Supplement</b>	Doc. No.: MD11-AMM-00-002
Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>	Issue: 05

## 4.6.2 Main door bell crank


The main door bell crank consists of multiple assemblies as illustrated in Figure 4-12.

### 4.6.2.1 Overview





No	Description	No	Description
1	Spring link	2	Spring bush
3	Spring bolt	4	Bell crank stop
5	Spring arm	6	Spring

		<b>Aircraft Maintenance Manual</b> <b>Supplement</b>		Doc. No.: MD11-AMM-00-002
Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>			Issue: 05


7	Bell crank pin	8	R-pin
9	Thimble	10	Crimp
11	Sleeve	12	Spring lug
13	Door close cable	14	Pully bracket
15	Pulley	16	Pulley bolt
17	Cable adjuster bolt	18	Cable adjuster
19	Bell crank fastening bolt	20	Pushrod fastening nut
21	Pushrod	22	Bell crank fastening nut

**Figure 4-12 Main door bell crank assembly**

#### **4.6.2.2 Removal procedure of Main door bell crank**

1. Extend the pylon to a position slightly below the extended position to ensure the main doors are fully open.
2. Switch off the RES master switch.
3. Disconnect the **Door close cable (13)** by removing the **R-pin (8)** and **Bell crank pin (7)**.
4. Disconnect the **Pushrod (21)** from the bell crank by undoing the **Pushrod fastening nut (20)**, or by disconnecting the pushrod from the main door hinge.
5. Disconnect the Springs (6) from the bell crank by unclipping the springs, loosening the **Spring bolt (3)**, or undoing the **Spring lug (12)**.
6. Remove the bell crank from the fuselage by undoing the four **Bell crank fastening bolts (19)**.


**CAUTION:** Removing and installing the pushrod could result in a length adjustment. In this case, the door setup should be done again (refer to the **Calibration & setup** section).

	<b>Aircraft Maintenance Manual Supplement</b>	Doc. No.: MD11-AMM-00-002
Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>	Issue: 05

#### 4.6.2.3 Installation procedure of Main door bell crank

1. Install the bell crank by fastening the four **Bell crank fastening bolts (19)**.
2. Connect the springs to the bell crank by clipping in the springs, installing the **Spring bolt (3)**, or fastening the **Spring lug (12)**.
3. Connect the **Pushrod (21)** to the bell crank and fix it in place using the **Pushrod fastening nut (20)**.
4. Connect the **Door close cable (13)** by installing the **Bell crank pin (7)** and **R-pin (8)**.


**CAUTION:** Removing and installing the pushrod, could result in a length adjustment. In this case, the door setup should be done again (refer to the **Calibration & setup** section).

	<b>Aircraft Maintenance Manual</b> <b>Supplement</b>		Doc. MD11-AMM-00-002
	Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>	Issue: 05


### 4.6.3 Main doors (first option of RES doors configuration)

The main doors consist of a left and right door, as illustrated in Figure 4-13.

#### 4.6.3.1 Overview



No	Description	No	Description
1	Front door hinges	2	Left main door (with four door cutout)
3	Left main door (with four door cutout)	4	Door hinge top
5	Pushrod bolt	6	Hinge bolt
7	Door hinge bottom	8	Rod end
9	Pushrod	10	Pushrod fastening nut

	<b>Aircraft Maintenance Manual</b> <b>Supplement</b>		Doc. No.: MD11-AMM-00-002
	Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>	Issue: 05

11	Left main door (optional no cutout)		Left main door (optional no cutout)
----	-------------------------------------	--	-------------------------------------

**Figure 4-13 Main doors assembly**

#### 4.6.3.2 Maintenance & Checks of main doors

The main doors should seat properly during full pylon retraction and extension. The main doors should not touch the outside of the fuselage when they are fully open. The doors should open and close smoothly – this could be verified by cycling the pylon in and out. If this is not the case, refer to the **Calibration & setup** section.

#### 4.6.3.3 Removal procedure of main doors

1. Extend the pylon to a position slightly below the extended position to ensure the main doors are fully open.
2. Switch off the RES master switch.
3. Disconnect the pushrod from the **Door hinge top (4)** by undoing the **Pushrod fastening nut (10)**.
4. Undo the **Hinge bolt (6)** of both the front and rear door hinges.
5. Remove the main door from the fuselage of the aircraft.


**CAUTION:** Removing and installing the pushrod could result in a length adjustment. In this case, the door setup should be done again (refer to the **Calibration & setup** section).


#### 4.6.3.4 Installation procedure of main doors

1. Install the main door to the fuselage by fastening the **Hinge bolts (6)** of the front and rear hinges.
2. Connect the pushrod to the **Door hinge top (4)** by fastening the **Pushrod fastening nut (10)**.

**CAUTION:** Removing and installing the pushrod could result in a length adjustment. In this case, the door setup should be done again (refer to the **Calibration & setup** section).

**NOTE:** As an option, the main doors may be configured with integrated front doors. In this configuration, there are no separate front doors or hinges. The door closing sequence must be adjusted accordingly to ensure the main doors do not close fully when the pylon is fully extended..


	<b>Aircraft Maintenance Manual Supplement</b>	Doc. No.: MD11-AMM-00-002
Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>	Issue: 05

	<b>Aircraft Maintenance Manual</b>	Doc. No.:	MD11-AMM-00-002
	<b>Supplement</b>		
Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>	Issue:	05

#### 4.6.4 Front doors (first option of RES doors configuration)


The front doors (optional) are fixed to the main doors and are spring-operated as illustrated in Figure 4-14.

#### 4.6.5 Overview



No	Description	No	Description
1	Right front door	2	Left front door
3	Front door hinge bolt	4	Front door bottom hinge
5	Front door top hinge	6	Front door hinge nut
7	Front door spring		

**Figure 4-14 Front doors assembly**

	<b>Aircraft Maintenance Manual Supplement</b>	Doc. No.: MD11-AMM-00-002
Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>	Issue: 05

#### 4.6.6 Removal procedure of front doors


1. Extend the pylon to a position slightly below the extended position to ensure the main doors are fully open.
2. Switch off the RES master switch.
3. Loosen the two **Front door hinge bolts (3)** to free a front door from the corresponding main door.

**NOTE:** The main doors can be completely removed to improve access.

#### 4.6.7 Installation of front doors

1. Fasten a front door to the main door by fastening the two **Front door hinge bolts (3)**.
2. Ensure that one end of the **Front door spring (7)** is hooked behind the Front door top hinge as indicated in the overview figure.


**CAUTION:** The order of washers and the other components should match Figure 4-14.

	<b>Aircraft Maintenance Manual</b>	Doc. No.:	MD11-AMM-00-002
	<b>Supplement</b>	Issue:	05
Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>		

## 4.7 Battery latches


The battery latches are located within the rear fuselage compartment. There are two battery latches, one for the left battery and the other for the right battery. They are critical in ensuring that the HV batteries are fastened in flight.

### 4.7.1 Overview



No	Description	No	Description
1	Battery latch composite assembly	2	Battery latch
3	Battery latch hinge bolt	4	Battery latch hinge nut
5	R-pin	6	Key ring 20mm
7	Grip knob	8	Battery latch thumb screw lock

**Figure 4-15 Battery latches**

	<b>Aircraft Maintenance Manual</b> <b>Supplement</b>	Doc. No.: MD11-AMM-00-002
Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>	Issue: 05


#### 4.7.2 Removal procedure of battery latches

1. Extend the pylon to a position slightly below the extended position to ensure the main doors are fully open.
2. Switch off the RES master switch.
3. Remove the **R-pin (5)**.
4. Remove the **Battery latch thumb screw lock (8)**.
5. Unscrew the **Grip knob (7)**.
6. Remove the **Battery latch (2)** by unfastening the **Battery latch hinge bolt (3)** and **Battery latch hinge nut (4)**.

#### 4.7.3 Installation of battery latches

1. Install the **Battery latch (2)** by fastening the **Battery latch hinge bolt (3)** and **Battery latch hinge nut (4)**.
2. Fasten the **Grip knob (7)**.
3. Install the **Battery latch thumb screw lock (8)**.
4. Install the **R-pin (5)**.

**CAUTION:** The battery latches should always be locked, if not, the motor will crash into the battery latch during retraction, preventing full retraction.

	<b>Aircraft Maintenance Manual</b> <b>Supplement</b>	Doc. No.: MD11-AMM-00-002
	Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>

## 4.8 Display and Control Unit (DCU)

The Display and Control Unit (DCU) is located on the instrument within the cockpit. The DCU provides the interface between the Pilot and the system. The DCU provides commands to the RFU and the motor controller to control the system.

### 4.8.1 Overview




Figure 4-16 DCU

### 4.8.2 Removal of DCU


The DCU is fastened with 4 screws on the instrument panel.

1. Disconnect the wiring loom from the DCU by delatching the D-sub clips.
2. Remove the four fastening screws located in the corners of the DCU.

### 4.8.3 Installation of DCU

1. Install the DCU into the instrument panel and fastening it using the four fastening screws located in the corners of the DCU.
2. Connect the wiring loom to the DCU by plugging in the connector and fasten it into place by latching the D-sub clips.

**CAUTION:** Be careful not to disturb or damage other wires within the binnacle when removing the DCU.

	<b>Aircraft Maintenance Manual</b>  <b>Supplement</b>	Doc. No.: MD11-AMM-00-002
Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>	Issue: 05

## 4.9 LXNAV Bridge

### 4.9.1 Overview

The LXNAV bridge is an optional extra providing an interface between the DCU and LXNAV flight computers. This enables the LXNAV flight computer to be able to display various parameters of the RES system, like HV battery SOC, RPM, Motor controller temperature, etc.


### 4.9.2 Removal of LXNAV bridge

1. Ensure the master switch of the system is switched off.
2. Disconnect the Microphone plug located on the binnacle cover.
3. Remove the canopy of the aircraft.
4. Remove the binnacle cover and unplug the microphone plug located in the binnacle.
5. Disconnect both D-sub connectors on both ends of the bridge.
6. Remove the bridge from the aircraft.

### 4.9.3 Installation LXNAV bridge

1. Connect the two D-sub connectors to the bridge. If there are no bridge D-sub connectors installed, refer to the **Wiring loom** section.
2. Verify the orientation of the bridge. It should match the sticker on the bridge.
3. Plug in the binnacle cover microphone plug.
4. Fasten the binnacle cover.
5. Plug in the microphone.
6. Install the canopy.

**CAUTION:** Ensure the type of bridge is approved by the manufacturer before installation is approved.

	<b>Aircraft Maintenance Manual</b>		Doc. No.:	MD11-AMM-00-002
	<b>Supplement</b>			
Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>		Issue:	05

## 4.10 Motor controller assembly

The motor controller regulates the operation of the Electric motor. The motor controller assembly consists of the motor controller unit and the controller cooling assembly. There are two variants available, namely the air-cooled system and the liquid-cooled system.


### 4.10.1 Air-cooled motor controller assembly

#### 4.10.1.1 Overview


The air-cooled motor controller assembly is installed between Bulkhead B7 and B8 below the wing spars.

The controller board is housed in a carbon enclosure. High-voltage wiring is connected to the sides of the motor controller assembly. Two air cooling fans are attached to the rear of the controller unit.


Figure 4-17 and Figure 4-18 illustrate the position of the air-cooled motor controller system.



No	Description	No	Description
1	Air-cooled motor controller assembly	2	B5 bulkhead
3	Controller cooling fan plate		


	<b>Aircraft Maintenance Manual</b> <b>Supplement</b>	Doc. MD11-AMM-00-002
	Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>


**Figure 4-17 Air-cooled motor controller assembly overview**



No	Description	No	Description
1	Motor Controller box cover	2	B5 Cover
3	Bugwiper connector back plate	4	Front fastening bolt
5	Ground bolt	6	Cable glands
7	Rear fastening bolt	8	Cooling fan
9	Controller cooling fan plate	10	Grommet
11	D-sub connectors	12	Box top
13	Box bottom	14	High-voltage ring terminals


**Figure 4-18 Air-cooled motor controller assembly detailed overview**

	<b>Aircraft Maintenance Manual Supplement</b>	Doc. No.: MD11-AMM-00-002
Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>	Issue: 05

	<b>Aircraft Maintenance Manual</b> <b>Supplement</b>	Doc. No.: MD11-AMM-00-002
	Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>


#### 4.10.1.2 Removal of the air-cooled motor controller assembly from the fuselage

1. Ensure the master switch of the system is switched off.
2. Remove the **B5 Cover (2)** by unscrewing the four bolts located in the corners of the cover.
3. Undo the **Bug wiper connector back plate (3)** by loosening its two fastening bolts.
4. The battery cable can be pulled through the grommet and the **B5 Cover (2)** is completely removed.
5. Remove the four **D-sub connectors (11)** located on the right side of the motor controller assembly.
6. Remove the **Motor controller box cover (1)**.
7. Loosen the three **Cable glands (6)** to ensure they are not clamping the wires anymore.
8. Remove the **Ground bolt (5)**.




**Figure 4-19 Motor controller assembly top view**

9. Loosen the five bolts retaining the **High voltage ring terminals (14)** and remove the high voltage wires from the box.
10. Loosen the two **Rear fastening bolts (7)** and three **Front fastening bolts (4)**.
11. Remove the motor controller assembly from the fuselage. Be careful to clear all wiring while removing the assembly as the wiring loom can be damaged.

	<b>Aircraft Maintenance Manual</b>	Doc. No.:	MD11-AMM-00-002
	<b>Supplement</b>		
Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>	Issue:	05


#### 4.10.1.3 Removal of the air-cooled motor controller assembly PCBs

Three PCBs are located within the motor controller assembly, as illustrated in Figure 4-20.



No	Description	No	Description
15	Box top fastening bolts	16	RCB PCB Fastening bolts
17	Ribbon cable	18	Motor controller PCB
19	D-sub assembly	20	RCB PCB
21	PCB ground wiring	22	Motor controller PCB fastening bolts

**Figure 4-20 Motor controller PCBs**


	<b>Aircraft Maintenance Manual</b>		Doc. MD11-AMM-00-002
	<b>Supplement</b>		No.:
Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>	Issue:	05

1. Remove the motor controller **Box Top (12)** by removing the six **Box top fastening bolts (15)**.
2. Lift the **Box Top (12)** from the bottom assembly.
3. Removed the **PCB ground wiring (21)** from the **Box Top (12)** by pulling it through the grommet located in the **Box Top (12)**.
4. Remove the **RCB PCB (20)** by unfastening the four **RCB PCB bolts (16)**.
5. Remove The **Motor controller PCB (18)** by unfastening the six **Motor controller PCB bolts (22)**.


**CAUTION:** Do not lift the **Box Top (12)** too far away, as the **Ribbon cable (17)** must be disconnected from the D-sub assembly first. The **D-sub assembly (19)** is fastened to the **Box Top (12)**.

#### 4.10.1.4 Removal of the cooling fans

There are two cooling fans located behind the motor controller assembly. These fans can be accessed from the rear fuselage compartment or the cockpit if the motor controller assembly is removed.



No	Description	No	Description
23	Fan plate fastening bolts	24	Fan plate
25	Cooling fan	26	Cooling fan fastening bolts

	<b>Aircraft Maintenance Manual</b> <b>Supplement</b>		Doc. No.: MD11-AMM-00-002
	Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>	Issue: 05

27	Fan finger guard		
----	------------------	--	--

**Figure 4-21 Cooling fans**

The **Cooling fans (25)** can be removed with the motor controller assembly installed or after it has been removed. If the motor controller assembly is removed, the Fan plate (24) can also be removed.

1. Ensure the master switch of the system is switched off.
2. Disconnect the wiring of the fans.
3. Loosen the five **Fan plate fastening bolts (23)**.
4. Remove the **Fan plate (24)** from the fuselage.
5. Loosen the eight **Cooling fan fastening bolts (26)**.
6. Remove the **Cooling fans (25)**.

**NOTE:** Steps 2-3 can be skipped if the motor controller assembly is installed.


#### **4.10.1.5 Installation of air-cooled motor controller assembly**

The installation of the motor assembly consists of the following three installation procedures:

- Installation of the cooling fans
- Installation of the motor controller assembly PCBs
- Installation of the motor controller assembly into the fuselage

##### **4.10.1.5.1 Installation of the cooling fans**

1. Fasten the **Cooling fans (25)** to the **Fan plate (24)** using the eight **Cooling fan fastening bolts (26)**.
2. Fasten the **Fan plate (24)** to the fuselage using the five **Fan plate fastening bolts (23)**. This step can be skipped if the **Fan plate (24)** was not removed from the fuselage.
3. Connect the fan wires.

	<b>Aircraft Maintenance Manual</b> <b>Supplement</b>		Doc. MD11-AMM-00-002
	Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>	Issue: 05

#### 4.10.1.5.2 Installation of the air-cooled motor controller assembly PCBs


1. Fasten the **Motor controller PCB (18)** to the **Box bottom (13)** using the six **Motor controller PCB fastening bolts (22)**.
2. Fasten the **RCB PCB (20)** to the **Box Top (12)** by fastening the four **RCB PCB Fastening bolts (16)**. Do not forget to include the spacers.
3. Make sure the **PCB ground wiring (21)** is connected to the **Motor controller PCB (18)** firmly at both connection points. Ensure the **PCB ground wiring (21)** passes through the grommet in the **Box Top (12)**.
4. The ribbon cable of the **Motor controller PCB (18)** should be connected to the **D-sub assembly (19)**.
5. The **Box Top (12)** can now be lowered onto the **Box Bottom (13)** and fastened using the six **Box top fastening bolts (15)**.
6. Insert the motor controller assembly back into the fuselage. Be sure not to disturb any wiring when inserting the motor controller assembly.
7. Fasten the motor controller assembly to the fuselage using the two **Rear fastening bolts (7)** and three **Front fastening bolts (4)**.

**WARNING:** Omitting the spacers in step 2 may cause the RCB PCB (19) to short circuit, leading to electrical failure and creating a potential fire hazard.

**WARNING:** If the ground wiring is not connected in step 3 to the **Motor controller PCB (18)**, the motor and motor controller will not operate correctly. This will increase EMF interference and could cause permanent damage to the Motor Controller.


**CAUTION:** There are wires which are routed from the right side of the fuselage to the left by passing underneath the motor controller. Do not pinch these wires between the motor controller assembly and the **Controller cooling fan plate (9)** in step 6.

**WARNING:** If the original motor controller PCB was replaced by a new motor controller PCB, the resolvers must be recalibrated (Refer to the Calibration & setup section). When the calibration is out, the motor could behave unpredictably and start rotating even if no power is requested by the DCU.

	<b>Aircraft Maintenance Manual</b> <b>Supplement</b>	Doc. No.: MD11-AMM-00-002
	Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>


#### 4.10.1.5.3 Installation of the air-cooled motor controller assembly into the fuselage


1. Install the motor controller assembly into the fuselage. Be careful to clear all the wiring in the fuselage while installing the assembly, as the wiring loom can be damaged.
2. Fasten the assembly using the two rear **Fastening bolts (7)** and three **Front fastening bolts (4)**.
3. Install the five high-voltage wires into the box. The wire colour identifications should be matched as illustrated in Figure 4-22.



**Figure 4-22 Motor controller HV wire sequence**

4. Fasten the five bolts retaining the **high-voltage ring terminals (12)**.
5. Tighten the three **Cable glands (6)**.
6. Fasten the four ring terminals listed below using the **Ground bolt (5)**. :
  - Cooling Fans ground
  - Motor ground
  - PCB ground
  - Ground bus wire
7. Ensure the ground bus wire is connected to the ground bus and the ground bolt.
8. Verify the continuity between the ground bus of the aircraft and the shielding of the HV wires U, V, and W. A needle can be used to protrude the external insulation of the wire. Figure 4-23 shows a graphical depiction of the HV wire.

	<b>Aircraft Maintenance Manual</b> <b>Supplement</b>		Doc. No.: MD11-AMM-00-002
	Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>	Issue: 05



**Figure 4-23 HV wire**


9. Install the **Motor controller box cover (1)**.
10. Install the four **D-sub connectors (11)** located on the right side of the motor controller assembly.
11. Route the battery cable through the **Grommet (10)**, which is located in the **B5 cover (2)**.
12. Install the **Bug wiper connector back plate (3)**.
13. Install the **B5 cover (2)** by fastening the four bolts located in the corner of the cover.
14. The system can now be switched on to verify that there are no errors.

**WARNING:** The high voltage wires should be installed in the correct sequence, if not – the system could be damaged.

**WARNING:** The high voltage terminals should be fastened correctly in step 4. Ensure the washers are installed; if not, the bolt could bottom out and not retain the ring terminal. This will destroy the motor controller.

**WARNING:** If any one of the four wires in step 6 is excluded, the system will not work properly and can cause a major fire risk or damage to the system.

**WARNING:** No warning will be displayed if the cooling fans are not connected correctly. It is best to verify that the Cooling fans work by doing a ground run.

	<b>Aircraft Maintenance Manual</b>		Doc. No.:	MD11-AMM-00-002
	<b>Supplement</b>		No.:	
Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>	Issue:	05	


## 4.10.2 Liquid-cooled motor controller assembly

### 4.10.2.1 Overview

The liquid-cooled motor controller assembly is installed above the wheel box between Bulkhead B7 and B8 below the wing spars.


The controller board is housed in an aluminium enclosure. High-voltage wiring is connected to the rear of the motor controller assembly, facing the tail of the aircraft. Liquid cooling system tubes are connected to the controller unit.

The liquid-cooling system for the motor controller uses a reservoir.




No.	Description	No.	Description
1	B5 Bulkhead	2	Motor controller assembly
3	Controller box stands	4	Wheel Box

**Figure 4-24 Liquid-cooled motor controller overview**

	<b>Aircraft Maintenance Manual</b> <b>Supplement</b>	Doc. MD11-AMM-00-002
	Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>

#### 4.10.2.2 Removal of the liquid-cooled motor controller box from the fuselage


The glove box assembly and HV master batteries need to be removed before the motor controller box is removed from the fuselage. Figure 4-25 shows the location of the glove box assembly and the master batteries. Figure 4-26 gives an overview of the liquid-cooled motor controller assembly and Figure 4-27 gives a top view of the liquid-cooled motor controller.




No.	Description	No.	Description
1	Glove box assembly	2	HV batteries

**Figure 4-25 Glove box and battery removal**


1. Disconnect the Bug wiper connector back plate (item 8 in Figure 4-26) by loosening its two fastening bolts.
2. Pull the battery cable through the grommet and the Glove box assembly (item 1 in Figure 4-25).
3. Remove the Glove box assembly (item 1 in Figure 4-25) by removing the four bolts that hold the assembly in position.
4. Ensure both HV master batteries (item 2 in Figure 4-25) are removed from the aircraft.
5. Ensure the RES master switch is OFF.
6. Remove the connectors to the RFU-Isometer assembly (item 6 in Figure 4-26) and the RCB PCB assembly (item 7 in Figure 4-26).
7. Remove the D-sub connectors (item 4 in Figure 4-26) from the controller box assembly.
8. Undo the eight bolts of the Motor controller lid (item 11 in Figure 4-26) and remove the lid.
9. Loosen the three Cable glands (item 9 in Figure 4-26) to ensure they are not clamping the wires.
10. Remove the bolts retaining the high voltage ring terminals (item 1 in Figure 4-27) to the Motor controller PCB (item 2 in Figure 4-27).
11. Remove the high-voltage wires from the box.

	<b>Aircraft Maintenance Manual</b> <b>Supplement</b>	Doc. MD11-AMM-00-002
	Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>

12. Remove the Water Lines (item 3 in Figure 4-27) from Elbow fittings (item 2 in Figure 4-26).
13. Loosen and remove the Mounting bolts (item 3 in Figure 4-26) within the wheel box, located at the top of the wheel box.
14. Remove the motor controller assembly from the fuselage.




No.	Description	No.	Description
1	Motor controller assembly	2	Elbow fitting
3	Mounting bolt	4	D-sub connectors
5	Glove box assembly	6	RFU-Isometer assembly
7	RCB PCB assembly	8	Bug wiper connector back plate

		<b>Aircraft Maintenance Manual Supplement</b>		Doc. No.: MD11-AMM-00-002
Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>			Issue: 05

9	Cable glands	10	High-voltage wires
11	Motor controller Lid		

**Figure 4-26 Liquid-cooled motor controller assembly overview**




No.	Description	No.	Description
1	High-voltage ring terminals	2	Motor Controller PCB
3	Water lines		

**Figure 4-27 Liquid-cooled motor controller top view**

**CAUTION:** Do not spill undrained coolant. Spilled liquid may cause damage to the connectors and other components.


**CAUTION:** Clear all wiring while removing the assembly, as the wiring loom can be damaged.

	<b>Aircraft Maintenance Manual</b>	Doc. No.:	MD11-AMM-00-002
	<b>Supplement</b>		
Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>	Issue:	05

#### 4.10.2.3 Removal of the motor controller assembly PCBs


Two PCBs are located within the motor controller assembly:


- Motor controller PCB (item 2 in Figure 4-27)
- RCB PCB (item 7 in Figure 4-26)




No.	Description	No.	Description
1	Cold Plate	2	Cold plate mount bolts
3	Position to hold motor controller assembly	4	Box assembly

**Figure 4-28 Liquid-cooled motor controller assembly oblique and bottom view**

	<b>Aircraft Maintenance Manual Supplement</b>	Doc. No.: MD11-AMM-00-002
Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>	Issue: 05

	<b>Aircraft Maintenance Manual</b>		Doc. No.:	MD11-AMM-00-002
	<b>Supplement</b>		No.:	
Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>	Issue:	05	

1. Disconnect the ribbon cable from the D-sub assembly (item 4 in Figure 4-26).
2. Remove the D-sub assembly to be able to gain access to the motor controller PCB (item 2 in Figure 4-27).
3. Unfasten the Cold Plate mount bolts (item 2 in Figure 4-28).
4. Lift the motor controller box and remove the motor controller from the Box assembly (item 4 in Figure 4-28).
5. Remove the motor controller PCB from the cold plate (item 1 in Figure 4-28) by unfastening the Cold plate mounting bolts (item 1 in Figure 4-29).



No.	Description	No.	Description
1	Cold Plate mounting bolts		


**Figure 4-29 Cold plate fitment**

#### **4.10.2.4 Installation of the liquid-cooled motor controller system**

Installation of the liquid cooling system and the motor controller assembly consists of the following procedures:


- Installation of the motor controller system, DC-DC converter and RCB PCB assembly into the fuselage.
- Installation of the radiator and piping system into the fuselage.
- Bleeding of the liquid cooling system.

**NOTE:** Unless otherwise specified, installation follows the removal procedure in reverse sequence.

	<b>Aircraft Maintenance Manual</b> <b>Supplement</b>		Doc. MD11-AMM-00-002
	Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>	Issue: 05


#### 4.10.2.5 Assembly of the liquid-cooled motor controller box

1. Apply a thin film ( $0.2\text{mm} \leq x \leq 0.7 \text{ mm}$ ) of thermal paste onto the cold plate ribs, as indicated in Figure 4-30.
2. Install the 94 x 3 O-ring (Nitrile Rubber) into the groove, as indicated in Figure 4-30.




**Figure 4-30 Thermal paste and O-ring positions**

3. Fasten the motor controller PCB to the cold plate and use Loctite 243 on the bolts.
4. Apply a thin layer ( $0.2\text{mm} \leq x \leq 0.7 \text{ mm}$ ) of thermal paste onto the bottom of the cold plate as illustrated in Figure 4-31.



**Figure 4-31 Thermal paste on bottom of cold plate**


5. Secure the cold plate to the motor controller box using M3-size bolts and Loctite 243 torqued to a value of 8-12 Nm.
6. Install the D-sub assembly (item 4 in Figure 4-26) into the box and fasten it into position.

	<b>Aircraft Maintenance Manual</b> <b>Supplement</b>	Doc. No.:	MD11-AMM-00-002
	Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>	Issue:

7. Connect the ribbon cable from the Motor controller PCB (item 2 in Figure 4-27) to the D-sub assembly.
8. Install Elbow fitting (item 2 in Figure 4-26) to Cold plate (item 1 in Figure 4-28).


#### 4.10.2.6 Installation of motor controller and associated components

1. Install the box stands into the fuselage and fasten Box assembly (item 4 in Figure 4-28) into position as shown in Figure 4-32.




**Figure 4-32 Box stands fitment**


2. Install DC-DC converter (item 1 in Figure 4-44) to DC-DC converter brackets (item 5 in Figure 4-44).
3. Install RCB into PCB housing and fasten with RCB PCB mounting bolts (item 4 in Figure 4-44).
4. Fit high-voltage wire (item 10 in Figure 4-26) through Cable glands (item 9 in Figure 4-26) and Grommets and connect High voltage terminals (item 1 in Figure 4-27) to Motor controller PCB (item 2 in Figure 4-27). The wire colour identifications should be matched as illustrated in Figure 4-33.



**Figure 4-33 Motor controller HV wire sequence**


5. Tighten the three Cable glands (item 9 in Figure 4-26).
6. Install ground wire to motor controller PCB and ground bolt, connecting to the box as shown in Figure 4-34.

	<b>Aircraft Maintenance Manual</b> <b>Supplement</b>	Doc. No.:	MD11-AMM-00-002
	Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>	Issue:




**Figure 4-34 Motor controller ground wire mounting point**

7. Fasten the five ring terminals as listed below:
  - Cooling fans ground
  - Motor ground
  - PCB ground
  - Ground bus wire
  - Water pump ground
8. Ensure the ground bus wire is connected to the ground bus and the ground bolt.
9. Verify the continuity between the ground bus of the aircraft and the shielding of the HV wires U, V and W (refer to Figure 4-33). A needle can be used to protrude the external insulation of the wire as shown in Figure 4-35.



**Figure 4-35 Wiring detail**

10. Install the D-sub connectors located on the left and right side of the motor controller assembly.
11. Install the Glove box assembly (item 5 in Figure 4-26)
12. Route the battery cable through the grommet which is located in the glove box assembly.
13. Install the Bug wiper connector back plate.
14. Install and fasten the Glove box assembly into position with the four bolts located in the corner of the assembly.
15. Install the Motor controller lid (item 2 in Figure 4-27) and fasten into position with M4 bolts.

	<b>Aircraft Maintenance Manual Supplement</b>	Doc. No.: MD11-AMM-00-002
Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>	Issue: 05


16. The system can now be switched on to verify that there are no errors.

**WARNING:** The high voltage terminals should be fastened in step 4. Ensure the washers are installed; if not, the bolts could bottom out and not retain the ring terminal. This will destroy the motor controller.

**WARNING:** If the ground wiring is not connected to the Motor Controller PCB (item 2 in Figure 4-27) in step 6, the motor and motor controller will not operate correctly. This will increase EMF interference and could cause permanent damage to the motor controller.

**WARNING:** If any one of the five wires listed in step 7 is excluded, the system will not work properly and can cause a major risk of damage to the system.

**WARNING:** No warning will be displayed if the cooling fan and water pump are not connected correctly. It is best to verify that the cooling fan and water pump work by doing a ground run.

	<b>Aircraft Maintenance Manual</b>	Doc. No.:	MD11-AMM-00-002
	<b>Supplement</b>		
Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>	Issue:	05

### 4.10.3 Liquid-cooling system for the motor controller


#### 4.10.3.1 Overview

The liquid-cooling system for the motor controller consists of 3 main components:

- Radiator unit
- Water pump with liquid transfer pipes
- Liquid Reservoir unit


#### 4.10.3.2 Radiator Unit

The radiator unit consists of the radiator and integrated fan.




No.	Description	No.	Description
1	Radiator support plate	2	Fan
3	Radiator	4	Radiator mounting bolts
5	Fan guard	6	Washers

**Figure 4-36 Radiator system installation**

	<b>Aircraft Maintenance Manual</b> <b>Supplement</b>		Doc. No.: MD11-AMM-00-002
	Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>	Issue: 05

### 4.10.3.3 Water pump assembly with pipes


The piping system includes the pump assembly, and transfer tubes.




No.	Description	No.	Description
1	Water pump reducer	2	Threaded inline fitting

**Figure 4-37 Water pump reducer and threaded inline fitting**

**CAUTION:** Connect the water outlet to the radial port and the water inlet to the axial port of the pump. Incorrect routing will prevent proper bleeding of the liquid cooling system and impair system functionality.



No.	Description	No.	Description
1	B9-1	2	B9
3	Engine bay water lines	4	Pylon tower
5	Battery bed	6	B8
7	Battery latch	8	Reservoir
9	Threaded elbow fitting	10	No-spill fitting
11	Tee fitting	12	Elbow fitting
13	Water line from cold plate	14	Water line to cold plate

	<b>Aircraft Maintenance Manual</b>	Doc. No.:	MD11-AMM-00-002
	<b>Supplement</b>		
Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>	Issue:	05


**Figure 4-38 Radiator and water pump connections**

#### 4.10.3.4 Reservoir unit

To manage the expansion of liquid heating up during operation, a reservoir unit is installed. The reservoir unit has a glass cylinder with minimum and maximum levels to allow the checking of the correct the cooling liquid level. The glass cylinder is contained within two aluminium caps, which have the connections to the coolant pipes and a filler cap for topping up the coolant.


##### 4.10.3.4.1 Reservoir


The reservoir, mounted adjacent to the base of the pylon, accommodates liquid expansion due to temperature increase. The reservoir allows the pilot to verify coolant quantity via level markings on the translucent cylinder.



No.	Description	No.	Description
1	Elbow Fitting OD4	2	Blanking plug
3	Thread to Tube Elbow Fitting OD10	4	Reservoir bracket
5	Stainless Steel cable tie (max)	6	Stainless Steel cable tie (min)
7	Reservoir		

**Figure 4-39 Reservoir assembly**

	<b>Aircraft Maintenance Manual</b>		Doc. No.:	MD11-AMM-00-002
	<b>Supplement</b>		No.:	
Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>	Issue:	05	



No.	Description	No.	Description
1	Overflow tube		


**Figure 4-40 Overflow tube location**

#### 4.10.3.5 Coolant

The liquid system is sensitive to changes in ambient temperature. To avoid freezing of the coolant, it is advised to add an “anti-freeze” (Propylene Glycol) to the liquid system.

Depending on the environmental temperatures in which the glider will be operating, a coolant mixture of propylene glycol needs to be added to the liquid cooling system. If the temperatures are above 0°C, no propylene glycol is required. However, if the temperatures drop below 0°C, a mixture of 1 part propylene glycol to 2.2 parts water (31.25% propylene glycol) should be added. This mixture provides protection against exposure down to -18°C.

**NOTE:** No specific brand or manufacturer of propylene glycol is recommended.


	<b>Aircraft Maintenance Manual Supplement</b>	Doc. No.: MD11-AMM-00-002
Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>	Issue: 05

#### 4.10.4 Maintenance (Reservoir)

##### 4.10.4.1 Inspection procedure for liquid cooling system

1. Inspect coolant level in reservoir.  
Verify that the coolant level is between the **MIN** and **MAX** indicators on the reservoir. If the level is below MIN, coolant must be added. If it is above MAX, the system may be overfilled and should be corrected.
2. Inspect the coolant tubes, radiator and cold plate for leakage.
3. Disconnect the pump from the aircraft's electrical system.
4. Connect the pump to an external 12V power supply.
5. Listen for cavitation noises from the pump.
6. In the case of cavitation noises being present, refer to section 4.10.4.4.


**NOTE:** Coolant leakage may be indicated by a low fluid level, which can cause the motor controller to shut down during operation to prevent overheating.

	<b>Aircraft Maintenance Manual</b> <b>Supplement</b>	Doc. MD11-AMM-00-002
	Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>

#### 4.10.4.2 Draining of the liquid cooling system

The following section describes the process to drain liquid from the system. Refer to Figure 4-41 for the components involved in draining.


**WARNING:** Do not proceed with any maintenance activities if the HV batteries have not been removed.



No.	Description	No.	Description
1	Radiator	2	Coolant return pipe
3	12V Water Pump	4	No spill fitting
5	Tee fitting		

**Figure 4-41 Radiator assembly**


1. Raise the tail of the aircraft to approximately 75 cm to allow the reservoir fluid to flow towards the drain hole located at B9.
2. Disconnect the Coolant return pipe (2) by pushing the blue ring inwards while gently pulling the pipe out to disconnect from the T-Fitting (5) as shown in Figure 4-41.
3. Connect a 400mm, OD 10mm plastic tube to the No-Spill Fitting (4) as shown in Figure 4-41.
4. Seal off Tee Fitting (5), from which the black tubing was removed, using your finger.
5. While sealing Tee Fitting (5), apply some pressure (not more than 0.2 bar) by blowing into the tube connected to No-spill Fitting (4) during step 3.
6. Coolant will be discharged from Coolant return pipe (2).

	<b>Aircraft Maintenance Manual</b>	Doc. No.:	MD11-AMM-00-002
	<b>Supplement</b>		
Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>	Issue:	05

7. Continue blowing on the connected tube until all the coolant has been drained from the system.
8. Once the system is drained reconnect Coolant return pipe (2) to Tee Fitting (5) and remove the tube from the No-Spill Fitting (4).


#### 4.10.4.3 Removal of radiator and pump assembly

Refer to Figure 4-42. The radiator assembly is supported by the Radiator support plate (1)



No.	Description	No.	Description
1	Radiator support plate	2	Fan
3	Radiator	4	Water pump
5	Water pump bracket	6	Radiator mounting bolts
7	Water pump mounting bolt	8	Threaded elbow fitting

**Figure 4-42 Radiator assembly**


	<b>Aircraft Maintenance Manual</b>  <b>Supplement</b>	Doc. No.: MD11-AMM-00-002
Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>	Issue: 05

1. Disconnect water lines from the two Threaded elbow fitting (8) connected to the radiator.
2. Loosen and remove the four Radiator mounting bolts (6).
3. Remove the Radiator (3), Fan guard and Fan (2) from the aircraft.
4. Remove the water lines from the Water pump (4).
5. Loosen the Water pump mounting bolt (7) from the bracket. DO NOT remove the bolt from the water pump.

#### 4.10.4.4 Bleeding procedure of the liquid cooling system


Ensure the electrical system is switched OFF and the high-voltage batteries have been removed. When bleeding the liquid cooling system, avoid spilling water onto the electrical system. Also, ensure that all the pipes and fittings have been connected in the correct positions and are sealing correctly.

1. Open the **Blanking plug** (item 2 in Figure 4-39) on the reservoir.
2. Add the coolant mixture to the reservoir (refer to the previous Section 4.10.3.5 for the coolant mixing ratios).
3. Connect a 1m Black Polyamide tube to the **No-spill fitting** (item 4 in Figure 4-41).
4. While maintaining a constant coolant level in the reservoir, siphon the coolant through the 1m black tube to draw water through the pump and radiator.
5. Once the coolant reaches the black tube, power on the pump using an external 12V power supply and maintain a constant coolant level in the reservoir between the MAX and MIN markings.
6. Disconnect the black tube from the air release system and continue operating the pump to bleed air from the **No-spill fitting** (item 4 in Figure 4-41).
7. Lift the tail of the aircraft to help trapped air escape from the radiator. Repeat this process periodically to ensure all air is released.
8. If the pump continues to produce a cavitation sound, turn it off for 10 minutes to allow small air bubbles to accumulate.
9. Switch the pump on and continue the bleeding process until the cavitation sound in the pump subsides.
10. Gently tap on the radiator and tubing to release trapped air from the system **while the pump is running**.

	<b>Aircraft Maintenance Manual Supplement</b>	Doc. No.: MD11-AMM-00-002
Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>	Issue: 05

11. Repeat the procedure until all remaining air is released and the cavitation noise from the pump ceases.
12. Fill the reservoir to the MAX coolant level mark, take care to avoid spilling.
13. Fasten the blanking plug back in to position reservoir.

**NOTE:** To verify correct installation, perform a leak test. Once the system is fully bled and no cavitation noises are present, operate the pump for 5 minutes and inspect all connections for coolant leaks.

	<b>Aircraft Maintenance Manual</b>		Doc. No.:	MD11-AMM-00-002
	<b>Supplement</b>		No.:	
Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>	Issue:	05	

## 4.11 DC-DC converter


The DC-DC converter converts the HV (400V) to 12 V to supplement the 12 V avionic batteries. The DC-DC converter is located on the left side of the wheel box and motor controller assembly. The DC-DC converter is fastened to two brackets which is bonded to B8 and the wheelbox.

### 4.11.1 Specification


**Table 4-3 DC-DC converter specifications**

Parameter	Value
Part number	107 02 075 00
Input Voltage	400 V
Output Voltage	14-16V
Max output current	15A for air cooled system 10A minium for water cooled system

### 4.11.2 Overview




No	Description	No	Description
1	DC-DC front bracket	2	DC-DC fastening bolts
3	DC-DC converter	4	DC-DC rear bracket

	<b>Aircraft Maintenance Manual</b>	Doc. MD11-AMM-00-002
	<b>Supplement</b>	No.:
Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>	Issue: 05

**Figure 4-43 DC-DC converter**

### 4.11.3 Removal of DC-DC converter and RCB PCB




No.	Description	No.	Description
1	DC-DC converter	2	DC-DC converter mounting bolts
3	RCB PCB assembly	4	RCB PCB mounting bolt
5	DC-DC converter brackets		

**Figure 4-44 DC-DC Converter and RCB PCB assembly**

1. Ensure the master switch of the system is switched off.
2. Derig the glider.
3. Disconnect the DC-DC converter wires.
4. Loosen and remove the four **DC-DC fastening bolts (2)**.
5. Remove the **DC-DC converter (3)** from the fuselage. Unfasten the DC-DC converter mounting bolts (2).
6. Unfasten the RCB PCB mounting bolts (4) from the RCB PCB assembly (3) to lid to gain access to the RCB PCB.

### 4.11.4 Installation

1. Insert the **DC-DC converter (3)** into the fuselage.
2. Fasten the **DC-DC converter (3)** to the front and rear DC-DC brackets using the four **DC-DC fastening bolts (2)**.
3. Connect the **DC-DC converter (3)** wires.


	<b>Aircraft Maintenance Manual</b>		Doc. No.:	MD11-AMM-00-002
	<b>Supplement</b>		No.:	
Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>	Issue:	05	

**CAUTION:** Be careful not to push out the captive nuts while inserting the fastening bolts.

## 4.12 Retraction and Fuses Unit (RFU)

The Retraction and Fuses Unit is responsible for the power distribution. Smart fuses are used in the RFU to protect the system from electric overload. The RFU is fastened to the same bracket as the IMD, which is located on the right side of the wheel box and motor controller.

### 4.12.1 Overview



No	Description	No	Description
1	IMD	2	RFU
3	IMD/RFU Bracket	4	IMD/RFU bracket bolts

Figure 4-45 RFU


### 4.12.2 Removal


1. Ensure the master switch of the system is switched off.
2. Disconnect the wires of the **IMD (1)** and **RFU (2)**.
3. Loosen the four **IMD/RFU bracket bolts (4)** to split the bracket.
4. Remove the **RFU (2)** and one side of the **IMD/RFU Bracket (3)**.

### 4.12.3 Installation

1. Install the **RFU (2)** into the one half of the **IMD/RFU Bracket (3)** and fasten the bracket to the other side of the bracket using the four **IMD/RFU bracket bolts (4)**.
2. Connect the wires of the **IMD (1)** and **RFU (2)**.

**CAUTION:** Be careful not to push out the top captive nuts while inserting the fastening bolts.

	<b>Aircraft Maintenance Manual Supplement</b>	Doc. No.: MD11-AMM-00-002
Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>	Issue: 05


	<b>Aircraft Maintenance Manual</b> <b>Supplement</b>		Doc. No.: MD11-AMM-00-002
	Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>	Issue: 05

## 4.13 Insulation Monitoring Device (IMD)

### 4.13.1 Overview

The Insulation Monitoring Device (IMD) is used to protect the system against high voltage leaks. If a high voltage leak is detected by the IMD, the HV system will be interrupted.

The IMD is fastened to the same bracket as the RFU, which is located on the right side of the wheel box and motor controller. The bracket consists of two halves, one side is removable, and the other side is bonded to the wheel box.




**Figure 4-46 Insulation monitoring device**

### 4.13.2 Removal

The removal process is the same as when removing the RFU (refer to the **Retraction and Fuses Unit (RFU)** section).

### 4.13.3 Installation


The installation process is the same as when installing the RFU (refer to the **Retraction and Fuses Unit (RFU)** section).

	<b>Aircraft Maintenance Manual</b>	Doc. No.:	MD11-AMM-00-002
	<b>Supplement</b>		
Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>	Issue:	05

## 4.14 HV Connectors


### 4.14.1 Overview

The RES system has three high-voltage connectors: one charge connector in the cockpit (left of the seat) and two HV battery connectors in the rear fuselage. The charge and battery connectors have opposite genders.



No	Description	No	Description
1	HV Battery connectors	2	Termination Plug
3	Thumb Screw	4	Charge Connector
5	HV Connector fastening bolts	6	Standoff
7	HV Pins	8	Communication Pins
9	Interlock Pins	10	Battery connector bracket base plate
11	Cockpit charging port plate	12	HV connector

**Figure 4-47 High Voltage Connectors**

	<b>Aircraft Maintenance Manual</b> <b>Supplement</b>		Doc. No.: MD11-AMM-00-002
	Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>	Issue: 05

The **Charge connector (4)** is used to charge either one or both of the HV batteries without removing them from the aircraft. Refer to **Wiring loom** section. When the charge plug is not used to charge the batteries, the correct **Termination plug (2)** should be used, if not the system will not be able to power up.

**HV battery connectors (1)** provide the interface between the aircraft HV system and the batteries. If only one battery is used, the correct **Termination plug (2)** should be used, if not the system will not be able to power up. Refer to **Wiring loom** section.


The termination plug should be securely fastened to the **Standoff (6)** using the two **Thumb screws (3)**.

#### 4.14.2 Maintenance & Checks of HV Connectors

The battery connectors must be kept clean, as dirt can contribute to malfunctions or damage to the connectors.

#### 4.14.3 Removal of HV Connectors

1. Remove the **Termination plug (2)** if installed.
2. Remove the **Battery connector bracket base plate (10)** by loosening the relative bolts.  
Skip this step if working on the charge connector.
3. Remove the **Cockpit charging port plate (11)**, by loosening the four bolts located in the corners of the plate.  
Skip this step if working on any one of the battery connectors.
4. Step 2/3 grants access to the fastening nuts located at the rear of the connector.
5. Loosen the two **HV connector fastening bolts (5)**.
6. The HV connector can now be removed from the surrounding structure/plate.
7. Use the Pin removal tool to remove the **Communication pins (8)**. The removal tool is slid over the communication pin from the front side - the pin can then be removed to the rear of the connector
8. The interlock pins are removed by disassembling the HV connector by removing the four **HV connector bolts (12)**. The block containing the interlock pins can then be removed and the rear retaining block unclipped – freeing the interlock pins.
9. The **HV Pins (7)** wires can be removed by loosening the bolt in the rear of the pin. The pin itself is pressed into the connector block.

	<b>Aircraft Maintenance Manual</b> <b>Supplement</b>		Doc. No.:	MD11-AMM-00-002	
	Type:	<b>JS-MD Single</b>	Model:	<b>JS 3 RES</b>	Issue:

**CAUTION:** Be careful to not damage any wires or wedge any wiring between the plate and the supporting structure.

#### 4.14.4 Installation of HV Connectors

The installation of a high-voltage connector consists of assembling the connector and then fitting it to the aircraft.

##### 4.14.4.1 Communication pins

1. The **Communication pins (8)** should be crimped to the correct wire.  
Refer to the **Wiring loom** section.
2. The **Communication pins (8)** can now be slid into the correct position within the connector block until it bottoms out. Pull on the wire to confirm the pin has locked into place.

##### 4.14.4.2 Interlock pins


1. The **Interlock Pins (9)** should be crimped to the correct wire.  
Refer to **Wiring loom** section.
2. The **Interlock Pins (9)** can now be inserted into the correct position within the connector block and held in place by clipping in the retaining block.
3. Slide the connector block into the connector and fasten the four **HV connector fastening bolts (5)**.

##### 4.14.4.3 HV pins

1. The **HV Pins (7)** are pressed into the connector block.
2. Connect the corresponding wires to the **HV Pins (7)** by fastening the rear bolt  
Refer to **Wiring loom** section.

##### 4.14.4.4 HV connector

1. Fasten the HV connector to the corresponding plate using the two **HV Connector fastening bolts (5)**.
2. Fasten the **Battery connector bracket base plate (10)** to the supporting structure by fastening the relevant bolts.  
Skip this step if working on the charge connector.
3. Install the **Cockpit charging port plate (11)**, by fastening the four bolts located in the corners of the plate.

	<b>Aircraft Maintenance Manual</b> <b>Supplement</b>		Doc. No.: MD11-AMM-00-002
	Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>	Issue: 05

Skip this step if working on any one of the battery connectors.

4. Install the relevant **Termination plug (2)**


**CAUTION:** Be careful to not damage any wires or wedge any wiring between the plate and the supporting structure.

### 4.15 Avionic Batteries

There are two avionic batteries located within the aircraft. The one battery is located within a hatch in the seatpan, aft of the control stick. The other avionic battery is located behind the seatback.

#### 4.15.1 Seatback battery

The seatback battery has a built-in circuit breaker.




Specification	Rating
Type	LiFePO4
Voltage	12.8V
Capacity	9.9Ah
Charge current max	3A
JS Part number	231 19 188 00

**Figure 4-48 Seatback specification**

#### 4.15.2 Seatpan battery

The seat pan battery has the following specification as indicated in the table below:

Specification	Rating
Type	LiFePO4
Voltage	12.8V
Capacity	9.9Ah
Charge current max	3A

	<b>Aircraft Maintenance Manual</b>	Doc. MD11-AMM-00-002
	<b>Supplement</b>	No.:
Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>	Issue: 05

Dimensions	80mmx54mmx138mm
JS Part number	107 05 055 00


**Table 4-4 Seatpan battery specification**

**NOTE:** It is good practice to unplug both avionic batteries during aircraft storage.

#### 4.16 Fire warning system

The fire warning system is independent of the RES system. It consists of two thermal switches, a heat-sensitive cable section located in the rear fuselage compartment, a 9 V battery, test button, LED, and buzzer.


The 9 V battery is located on the bottom right side of the binnacle (Figure 4-50) and can be removed by prying the battery holder with a screwdriver.




**Figure 4-49 Fire warning system**

No	Description	No	Description
1	Battery holder	2	Test button
3	LED		

**NOTE:** The 9 V battery must be replaced every two years (as part of the documented maintenance) or any time it fails a pre-flight test - whichever occurs sooner.


	<b>Aircraft Maintenance Manual Supplement</b>	Doc. No.: MD11-AMM-00-002
Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>	Issue: 05



*Intentionally left blank*

F

/

	<b>Aircraft Maintenance Manual</b> <b>Supplement</b>	Doc. No.: MD11-AMM-00-002
Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>	Issue: 05

## 5 CALIBRATION & SETUP


### 5.1 Actuator system setup

The actuator system must be set up to ensure the Pylon bell crank locks in the extended position and the pylon completely retracts during retraction.


1. Extend the pylon to a position slightly below the extended position to ensure the main doors are fully open.
2. Switch off the RES master switch.
3. Disconnect the actuator from the Pylon bell crank.
4. Disconnect the pylon driver arm from the pylon.
5. Disconnect the door drivers from the main doors.
6. Boot the DCU into Maintenance mode.


**WARNING:** The motor and motor controller are not activated in maintenance mode. If the actuator is cycled, the propeller will not auto-align, creating the risk of propeller misalignment during retraction or extension which could damage the actuator system or propeller.

7. Fully retract the actuator.
8. Connect the Pylon bell crank to the actuator.
9. Extend the actuator 20 – 50 mm.
10. Connect the Pylon driver arm to the pylon.
11. Extend the pylon and ensure that the Pylon driver arm locks into place and that the pylon clears the fuselage by adjusting the length of the actuator front and pylon driver arm.




**Figure 5-1 Fuselage clearance**

	<b>Aircraft Maintenance Manual Supplement</b>	Doc. No.: MD11-AMM-00-002
Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>	Issue: 05




**Figure 5-2 Pylon driver arm extension**

12. Slowly retract the pylon. The pylon should fully retract and lightly touch the bulkhead. The pylon should not press too hard into the bulkhead as illustrated in Figure 5-3.



**Figure 5-3 B9 Bulkhead**


	<b>Aircraft Maintenance Manual Supplement</b>	Doc. No.: MD11-AMM-00-002
Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>	Issue: 05

13. If the Pylon does not touch the bulkhead, adjust the pylon driver arm length.
14. Reconnect the main door drivers.
15. Cycle the actuator to ensure the pylon fully extends and retracts without any interference.
16. Should the main doors not close properly, refer to the Main door setup section.

**WARNING:** The pylon driver arm must lock into the pylon driver arm lock. If the joint does not fully extend, it could overload the supporting structures, causing mechanical failures

**NOTE:** The pylon drive arm length should remain unchanged if all geometry dimensions were matched prior to replacement and no adjustments were made during removal or installation.

**CAUTION:** The battery latches should always be locked; if not, the motor may crash into the battery latch during retraction, preventing full retraction.

	<b>Aircraft Maintenance Manual</b>  <b>Supplement</b>	Doc. No.: MD11-AMM-00-002
Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>	Issue: 05


## 5.2 Actuator calibration

If the actuator, RFU, or DCU is replaced, or if any actuator system mechanics are adjusted, recalibration of the actuator is recommended:

1. Switch off the RES main switch.
2. Boot the DCU into Maintenance mode.
3. Cycle the actuator until it is fully retracted and then fully extended.
4. Switch off the RES main switch.

**WARNING:** The motor and motor controller are not activated in maintenance mode. If the actuator is cycled, the propeller will not auto-align, creating the risk of propeller misalignment during retraction or extension which could damage the actuator system or propeller.

**CAUTION:** The battery latches should always be locked, if not, the motor will crash into the battery latch during retraction, preventing full retraction.


	<b>Aircraft Maintenance Manual Supplement</b>	Doc. No.: MD11-AMM-00-002
Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>	Issue: 05

### 5.3 Main door setup


The main door setup must be done to ensure the main doors completely close when fully retracted.


**NOTE:** Before any component change, be sure to match the component lengths – this will simplify the setup.

1. Switch off the RES main switch.
2. Remove one main door.
3. Boot the DCU into Maintenance mode.
4. Fully extend the pylon.
5. Retract the pylon to a  $\pm 45^\circ$  angle with the fuselage as reference.
6. Adjust the door driver length to ensure the door fully closes when the pylon is completely retracted. The door should close firmly and be pulled into position, deflecting the door inward into the fuselage (2-3mm) at the centre point.



**Figure 5-4 Main door setup**

	<b>Aircraft Maintenance Manual Supplement</b>	Doc. No.: MD11-AMM-00-002
Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>	Issue: 05




**Figure 5-5 Main door setup**

7. Disconnect the door that was set up.
8. Install the other main door and adjust its door driver to ensure it fully closes as well as per step 6.
9. Adjust the bell crank stop bolt to ensure the doors do not touch the fuselage during full extension and also not touch the motor while the pylon is being retracted or extended.
10. Adjust the length of the door closing cable so that the doors partially close in the extended position, just making contact with the pylon.

**WARNING:** The motor and motor controller are not activated in maintenance mode. If the actuator is cycled, the propeller will not auto-align, creating the risk of propeller misalignment during retraction or extension which could damage the actuator system or propeller.

**CAUTION:** The battery latches should always be locked, if not, the motor will crash into the battery latch during retraction, preventing full retraction.

	<b>Aircraft Maintenance Manual</b>  <b>Supplement</b>	Doc. No.: MD11-AMM-00-002
Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>	Issue: 05

## 5.4 Motor resolver calibration


The motor resolvers must be recalibrated if either the motor or motor controller were replaced. Each motor is matched to the motor controller. Changing any one of these two components creates a miss-match in settings, causing poor motor performance or could cause the motor to not work at all. It is advisable to remove the propeller before calibration.

1. Switch off the RES main switch.
2. Install both HV batteries.
3. Boot the DCU into Maintenance mode.
4. Fully extend the pylon to ensure the propeller clears the front and main doors.
5. Access the setup menu.
6. In the setup menu, scroll to the MotorCtl tab.
7. Move to the command field and enter it.
8. In the command field scroll unit "Motor resolver" is displayed.
9. Enter this command, and the field will change to red.
10. Once the calibration is completed the field will return to yellow.
11. The system can be switched off and switched on normally.

**WARNING:** If the resolver calibration is out, the motor could start rotating by itself. Be sure to clear the propeller during the start-up of the system until the calibration has been completed.

**WARNING:** The motor and motor controller are not activated in maintenance mode. If the actuator is cycled, the propeller will not auto-align, creating the risk of propeller misalignment during retraction or extension which could damage the actuator system or propeller.

**WARNING:** The motor will start to oscillate in step 9; be sure to clear the propeller.

	<b>Aircraft Maintenance Manual</b> <b>Supplement</b>	Doc. No.: MD11-AMM-00-002
Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>	Issue: 05


## 5.5 Propeller alignment

The propeller alignment must be redone if a new motor or motor controller was installed or if the orientation of the propeller relative to the motor was changed during propeller removal/replacement.


1. Switch off the RES main switch.
2. Install both HV batteries.
3. Boot the DCU into Maintenance mode.
4. Fully extend the pylon to ensure the propeller clears the front and main doors.
5. Access the setup menu.
6. In the setup menu, scroll to the MotorCtl tab.
7. Move to the command field and enter it.
8. In the command field scroll unit "Propeller position" is displayed.
9. Enter this command, and the field will change to red.
10. Rotate the DCU command knob to adjust the alignment position of the propeller.
11. Complete the setup by pressing the command knob, the field will change back to yellow.
12. The system can be switched off and switched on normally.

**WARNING:** If the propeller alignment is wrongly set, the propeller could cause damage to the main doors or fuselage. Be sure to clear the propeller during the start-up of the system until the calibration has been completed.

**WARNING:** The motor and motor controller are not activated in maintenance mode. If the actuator is cycled, the propeller will not auto-align, creating the risk of propeller misalignment during retraction or extension, which could damage the actuator system or propeller.

	<b>Aircraft Maintenance Manual Supplement</b>	Doc. No.: MD11-AMM-00-002
Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>	Issue: 05

*Intentionally left blank*

	<b>Aircraft Maintenance Manual</b>		Doc. No.:	MD11-AMM-00-002
	<b>Supplement</b>			
Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>	Issue:	05	


## 6 WIRING LOOM

The wiring loom of the RES is connected in parallel to the normal aircraft wiring loom. The control system RES is powered by the two avionic batteries installed in the aircraft. There is also a standalone fire warning system. The various electrical components should be wired according to the wiring diagrams illustrated below.

**NOTE:** Each wire has a wire number that can be traced to the origin and destination of the wire.


### 6.1 Display And Control Unit (DCU)

The DCU is located on the instrument panel within the cockpit of the aircraft. The DCU is responsible for the human-machine interface.



Wire number	Destination	Wire number	Destination
<b>125</b>	DC-DC on/off	<b>121</b>	RFU
<b>142</b>	Charge plug	<b>17</b>	GND
<b>116</b>	Motor controller	<b>135</b>	Left battery
<b>120</b>	RFU	<b>CAN GND</b>	Refer to 6.17
<b>16</b>	GND	<b>CAN_H</b>	Refer to 6.17
<b>117</b>	Motor controller	<b>CAN_L</b>	Refer to 6.17


Figure 6-1 DCU wiring

	<b>Aircraft Maintenance Manual</b> <b>Supplement</b>		Doc. MD11-AMM-00-002
	Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>	No.:
		Issue: 05	

**NOTE:** The wires used for the CAN communication should be a shielded twisted pair that is only grounded at the DCU.


## 6.2 RES Control Board (RCB)


The RES control board (RCB) is located within the motor controller assembly. The RCB is responsible for the switching and supply of avionic battery power to the RFU. The RCB is controlled by the battery selection switch located on the instrument panel within the cockpit of the aircraft. The RCB can also power the motor controller cooling fans.



Wire number	Destination	Wire number	Destination
143	FAN 2	125	Master switch
33	GND	139	Master switch
144	FAN 1	123	Battery 2
39	GND	128	RFU
145	Motor controller	127	RFU
126	RFU	122	Battery 1
124	DC-DC	135	Main selector
130	RFU	134	Main selector
129	RFU		



**Figure 6-2 RCB Wiring**

	<b>Aircraft Maintenance Manual Supplement</b>	Doc. No.: MD11-AMM-00-002
Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>	Issue: 05


	<b>Aircraft Maintenance Manual</b>	Doc. MD11-AMM-00-002
	<b>Supplement</b>	No.:
Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>	Issue: 05

### 6.3 Retraction And Fuses Unit (RFU)

The retraction and fuses unit (RFU) is located on the right side of the wheelbox. The RFU is responsible for all power distribution of the RES system and is controlled by the DCU.



Wire number	Destination	Wire number	Destination
126	RCB	32	GND
128	RCB	107	Actuator
30	GND	106	Actuator
112	Actuator	109	Actuator
110	Actuator	108	Actuator
27	Actuator	130	RCB
119	Right battery con	31	GND
111	Actuator	129	RCB
118	Left battery con	133	Charger con
115	IMD	CAN_L	Refer to 6.17
121	DCU	CAN_H	Refer to 6.17
120	DCU		


	<b>Aircraft Maintenance Manual</b>		Doc. No.:	MD11-AMM-00-002
	<b>Supplement</b>		No.:	
Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>	Issue:	05	

127	RCB		
-----	-----	--	--

**Figure 6-3 RFU Wiring**


## 6.4 Actuator

The actuator has an operating voltage of 12 V which is supplied by the RFU, which is controlled by the DCU. The actuator has built-in limit switches and a hall effect sensor to monitor the extension and retraction of the pylon.




Wire Number	Destination	Wire Number	Destination
110	RFU	108	RFU
111	RFU	109	RFU
27	RFU	106	RFU
112	RFU	107	RFU

**Figure 6-4 Actuator Wiring**

	<b>Aircraft Maintenance Manual</b>	Doc. MD11-AMM-00-002
	<b>Supplement</b>	No.:
Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>	Issue: 05

## 6.5 Left battery connector


The left battery connector is located in the rear fuselage compartment and is the connector interface for the left high voltage battery.



Wire number	Destination	Wire number	Destination
PSEN_GND	BMS Bootloader (Optional)	118	RFU
P_SEN	BMS Bootloader (Optional), 118	CAN_L	Refer to 6.17
RXD	Debug adapter	CAN_H	Refer to 6.17
TXD	Debug adapter	135	DCU
COM_GND	Debug adapter	136	Left battery
38	GND	137	Right Battery
19	GND	005	Motor Controller
008	Motor Controller		


Figure 6-5 Left battery connector wiring

**NOTE:** The debug adapter and bootloader switch is optional.

	<b>Aircraft Maintenance Manual</b> <b>Supplement</b>	Doc. MD11-AMM-00-002
	Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>


## 6.6 Charger connector

The charge connector is located to the left of the seatback, in front of the oxygen bottle holder. The charger connector provides the connector interface for the high voltage charger to be able to charge both or either high voltage batteries without removing the batteries from the fuselage.



Wire number	Destination	Wire number	Destination
001	Motor Controller	CAN_L	Refer to 6.17
002	Motor Controller	CAN_H	Refer to 6.17
142	DCU	37	GND
28	GND	138	Charge connector
133	RFU	135	Right Battery


Figure 6-6 Charger connector wiring

	<b>Aircraft Maintenance Manual</b> <b>Supplement</b>	Doc. MD11-AMM-00-002
	Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>

**CAUTION:** Remember to include bridge between pin X5-13 and X5-14. Without this bridge it will not be possible to charge the batteries in the aircraft.


## 6.7 DC-DC converter

The DC-DC converter converts the HV (400 V) to 12 V to supplement the 12 V avionic batteries. The DC-DC converter is located on the left side of the wheel box and motor controller assembly.




Wire Number	Destination	Wire Number	Destination
125	DCU	015	Motor controller
124	RFU	014	Motor controller
29	GND		

Figure 6-7 DC-DC Converter

	<b>Aircraft Maintenance Manual</b>	Doc. MD11-AMM-00-002
	<b>Supplement</b>	No.:
Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>	Issue: 05

## 6.8 Right battery connector

The right battery connector is located in the rear fuselage compartment and is the connector interface for the right high voltage battery.





Wire number	Destination	Wire number	Destination
PSEN_GND	BMS Bootloader (Optional)	CAN_L	Refer to 6.17
P_SEN	BMS Bootloader (Optional), 118	CAN_H	Refer to 6.17
RXD	Debug adapter	137	Left Battery Connector
TXD	Debug adapter	140	Right Battery Connector
SHIELD	Debug adapter	135	Charger Connector
36	GND	004	Motor controller
20	GND	007	Motor controller
119	RFU		

Figure 6-8 Right battery connector wiring

**NOTE:** The debug adapter and bootloader switch is optional.


**CAUTION:** The 10k ohm resistor has to be included for the system to work with both HV batteries. The 10k resistor is used to identify the connected battery.

	<b>Aircraft Maintenance Manual Supplement</b>	Doc. No.: MD11-AMM-00-002
Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>	Issue: 05

	<b>Aircraft Maintenance Manual</b> <b>Supplement</b>	Doc. MD11-AMM-00-002
	Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>

## 6.9 Motor, motor controller and resolvers


The resolvers provide position and rotation feedback to the motor controller which powers the motor.




Wire number	Destination	Wire number	Destination
010	IMD	004	Right battery connector
005	Left Battery connector	007	Right battery connector
001	Charger connector	22	GND
015	DC-DC	21	GND
009	IMD	23	GND
008	Left Battery connector	116	DCU
002	Charge connector	117	DCU
014	DC-DC	24	GND
CAN_L	Refer to 6.17	CAN_H	Refer to 6.17
145	RCB		

Figure 6-9 Motor, motor controller, and resolvers wiring

**CAUTION:** The motor controller PCB ground wire should be connected to the ground bolt as indicated in the removal and installation section of the motor controller assembly.


	<b>Aircraft Maintenance Manual</b>	Doc. No.:	MD11-AMM-00-002
	<b>Supplement</b>		
Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>	Issue:	05

## 6.10 Cooling fans




Wire Number	Destination	Wire Number	Destination
143	RCB	144	RCB
40	GND	41	GND

Figure 6-10 Cooling Fans wiring

	<b>Aircraft Maintenance Manual</b>		Doc. No.:	MD11-AMM-00-002
	<b>Supplement</b>		No.:	
Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>	Issue:	05	


## 6.11 Insulation Monitoring Device (IMD)

The insulation monitoring device (IMD) is fastened to the right side of the wheelbox. The IMD is used to detect any high voltage leaks.




Wire Number	Destination	Wire Number	Destination
14	GND	009	Motor controller
26	GND	CAN_L	Refer to 6.17
115	RFU	CAN_H	Refer to 6.17
010	Motor controller		

Figure 6-11 IMD Wiring

	<b>Aircraft Maintenance Manual</b> <b>Supplement</b>	Doc. MD11-AMM-00-002
	Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>


## 6.12 Avionic batteries

There are two avionic batteries located within the aircraft. The one battery is located within a hatch in the seat pan, aft of the control stick. The other avionic battery is located behind the seatback.




Wire Number	Destination	Wire Number	Destination
123	RCB	122	RCB
13	GND	12	GND

Figure 6-12 Avionics battery wiring

	<b>Aircraft Maintenance Manual</b>	Doc. MD11-AMM-00-002
	<b>Supplement</b>	No.:
Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>	Issue: 05


### 6.13 Ground bus



Wire number	Destination	Wire number	Destination
39	RCB	19	Left battery connector
33	RCB	38	Left battery connector
16	DCU	28	Charger connector
17	DCU	23	Motor controller
35	Avionic ground	21	Motor controller
13	Battery 2	22	Motor controller
12	Battery 1	36	Right battery connector
30	RFU	37	Charge connector
32	RFU	40	Cooling fan 2
31	RFU	41	Cooling fan 1
34	Fire warning		

Figure 6-13 Ground bus wiring

**NOTE:** The **GND rail cockpit** and **Rear GND rail** wires are interchangeable.

	<b>Aircraft Maintenance Manual</b> <b>Supplement</b>	Doc. MD11-AMM-00-002
	Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>

### 6.14 Supplementary fire warning system

The fire warning system is independent of the RES system. It consists of two thermal switches, a heat-sensitive cable section located in the rear fuselage compartment, a 9 V battery, test button, LED, and buzzer. The thermal switch(s) is located in the front corner of the fuselage compartment and the heat-sensitive cable is located within the rear fuselage are above the high voltage batteries underneath the lip of the engine doors opening. See Figure 6-15

The 9 V battery must be replaced every two years (as part of the documented maintenance) or any time it fails a pre-flight test - whichever occurs sooner.






Figure 6-14 Supplementary fire warning system wiring




	<b>Aircraft Maintenance Manual</b> <b>Supplement</b>	Doc. MD11-AMM-00-002
	Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>

**Figure 6-15 Location of thermal switch and heat-sensitive cable**


### 6.15 LXNAV bridge

The LXNAV bridge is an optional extra. The bridge provides an interface between the DCU and LXNAV flight computers. This enables the LXNAV flight computer to be able to display various parameters of the RES system like HV battery SOC, RPM, motor controller temperature, etc.




**Figure 6-16 LXNAV bridge**

The bridge has two nine-pin d-sub connectors. On one side is the standard LXNAV RS485 connector and on the other side is a standard CAN bus connector. The connectors have the following pinouts:




CAN BUS SIDE		RS485 SIDE	
Pin Number	Description	Pin Number	Description
2	CAN L	1	RS485-A
3	GND	4	RS485-B
5	GND	6/7	12 V
7	CAN H	5/9	GND


**Figure 6-17 LXNAV bridge wiring**


	<b>Aircraft Maintenance Manual Supplement</b>	Doc. No.: MD11-AMM-00-002
Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>	Issue: 05

**NOTE:** The orientation of the bridge should be correct as indicated on the sticker located on the bridge itself:

	<b>Aircraft Maintenance Manual Supplement</b>	Doc. No.: MD11-AMM-00-002
Type: <b>JS-MD Single</b>	Model: <b>JS 3 RES</b>	Issue: 05

## 6.16 Complete schematic



	<b>Aircraft Maintenance Manual</b> <b>Supplement</b>	Doc. No.: MD11-AMM-00-002
	Type: <b>JS-MD Single</b> Model: <b>JS 3 RES</b>	Issue: 05

## 6.17 Supplementary information and pictures

### 6.17.1 Interlocks & HV wiring

The diagrams illustrated in Figure 6-18 can be used to verify continuity between the illustrated pins.





Figure 6-18 Interlock and HV wiring

### 6.17.2 Termination plugs

Two termination plugs are used on the aircraft as described below:


#### 6.17.2.1 Charge socket termination plug

The charge socket termination plug is only removed to charge the HV batteries in the aircraft or to disable the system.



View same as in picture


Pin 19 and 20 bridged with 120 ohm resistor

	<b>Aircraft Maintenance Manual</b> <b>Supplement</b>	Doc. MD11-AMM-00-002 No.:
	Type: <b>JS-MD Single</b> Model: <b>JS 3 RES</b>	Issue: 05

**Figure 6-19 Charge connector termination plug**

### 6.17.2.2 Battery connector termination plug

The battery connector termination plug is used for single high voltage battery operation. The termination plug is inserted and fastened to the aircraft side battery connector of the absent battery.



**Figure 6-20 Battery connector termination plug**

### 6.17.3 Can wiring

The sequence of components connected to the CAN does not matter as long as the charge connector and DCU are at the ends of the daisy chain. The DCU is used to provide ground to the shielding. The termination resistors are located in the DCU and Charge termination plug/charger.

**CAUTION:** It is crucial for the CAN wiring to be shielded all the way to each connector. The CAN wiring is very susceptible to EMI caused by the motor and motor controller.

**CAUTION:** The wires used for the CAN communication should be a shielded twisted pair that is only grounded at the DCU.

## 7 LUBRICATION

### 7.1 Introduction

Hinge points and metal-to-metal contact points in the RES must be lubricated according to the lubrication schedule. All these points are initially lubricated in the factory but will need additional lubrication during the lifespan of the sailplane. This section describes the lubrication requirements of the RES.

### 7.2 Lubricants


The bearing surfaces must be lubricated with good quality grease. Most automobile greases are suitable. The following should not be used on the system:

- Thin spray penetrating oils, as these evaporate off fairly quickly.
- Any oils and greases containing silicon.
- Oils and greases containing Molybdenum Disulphide  $\text{MoS}_2$  are unsuitable on copper and brass bearings.

### 7.3 Lubrication plan

The lubrication is required annually as listed. See illustrations below:

- Door hinges.
- Ball links on the ends of the door pushrods.
- Bushes on the end of the actuator.



**Figure 7-1 Lubrication points**

*Intentionally left blank*

## 8 SYSTEM OPERATION

The RES is controlled by the following:

- Guarded RES master switch.
- Display and Control Unit interface.
- Battery selection switch.
- Motor Controller Circuit Breaker

### 8.1 Guarded RES master switch

The guarded RES master switch is a guarded switch on the instrument panel controlling the 12 V power supply to the RES. A battery selector switch enables the pilot to select 12 V from either of the removable 12 V batteries.



**Figure 8-1 Guarded RES master switch**

**NOTE:** The HV batteries cannot be enabled without the external 12 V power supply to the system. When the HV power rail has been activated the selected 12 V battery can be charged with a built-in DC-DC converted.


When the guarded RES master switch is switched ON, the built-in test procedure is initiated and the system will enter standby mode with the HV batteries not activated.

When the guarded RES master switch is switched OFF power to all RES systems except temperature monitoring is disconnected.

## 8.2 Display and control unit interface

The Display and Control Unit (DCU) has two primary controls:

- Command Button which can be rotated and pushed.
- Retract/Extend toggle switch to extend or retract the pylon.



**Figure 8-2 DCU Primary Controls**

The Command Button is used to:

- Control the DCU
  - Rotation – move the selected window or change values.
  - Push – select or enter a value.
- Control/change the desired power in the propulsion mode

## 8.3 Battery selection switch

The RES system can be powered from either avionic battery. The battery selection is made by the battery selection switch, which is located next to the guarded RES master switch.

## 8.4 Motor Controller Circuit Breaker



The 4A Klixon circuit breaker located on the instrument panel, adjacent to the guarded RES master switch, is labelled RES MC. This circuit breaker is intended for emergency use if the RES fails to respond to commands or power changes.


During any maintenance on the RES, the circuit breaker must be pulled (disconnected), unless specifically stated otherwise in the maintenance procedure.

**Caution:** The motor controller circuit breaker only controls the 12 V power supply to the motor controller. While this disables the controller, the 400 V high-voltage supply may still be present in the cables.

## 8.5 Operational mode

### 8.5.1 Standby

Standby mode is entered when the system is powered up and the built-in-test procedure has been completed successfully.



- Date and time (dd.mm.yyyy)
- Motor total time (hh: mm)
- Battery voltages (HV-L / 12 V / HV-R)
- State of Charge of HV batteries
- Maximum cell temperature in HV battery.
- Motor temperature
- Controller temperature

Figure 8-3 Standby screen.

When pushing the EXT/RETR switch upwards whilst in standby mode, the following actions are triggered:

1. The motor controller is switched ON and pre-charged.
2. HV batteries are switched ON and connected to the power rail.
3. The motor controller activates the propeller alignment.
4. The pylon spindle motor extends the pylon.


**NOTE:** The capacitors inside the inverter must be charged before the batteries are connected to the power rail. The message “Power bus Precharge” is displayed. This action takes a few seconds to complete.

**NOTE:** The battery latches should always be locked, if not, the motor will crash into the battery latch during retraction, preventing full retraction.

When pushing the EXT/RETR switch downwards whilst in standby mode the HV batteries are activated and the 12 V charging process starts.

### 8.5.2 Extension / Retraction Modes

Extension/retraction modes are entered from the standby or extended modes when the EXT/RETR switch is pushed.



**Figure 8-4 Extension/retraction screen**

- “AUTO” indicates that the pylon operation is done in automatic mode.
- The yellow triangles indicate that the propeller is stopped and in an aligned position.
- The yellow blinking arrow indicates the movement of the pylon.


The EXT/RETR switch is used to operate the pylon actuator as follows:

- A single click upwards is used to initiate the AUTO extension mode whilst retracted.
- A single click downwards is used to initiate the AUTO retraction mode whilst extended (any power setting).
- Manual pylon operation is entered by a single click in any direction whilst AUTO mode.

**CAUTION:** When the pylon is operated in manual mode, the system will allow retraction/extension regardless of the position of the propeller or the temperatures of components. A flashing arrow in the upper right corner of the display indicates manual mode operation.

### 8.5.3 Extended mode

When the pylon is fully extended the propulsion system is ready for operation.



- “Ready” indicates that the propulsion system is ready for operation.
- The yellow triangles indicate that the propeller stop is active and the propeller is kept aligned.


Figure 8-5 Extended screen

Propulsion mode is entered when the command button is rotated clockwise.

Retraction mode is activated when the EXT/RETR switch is pushed downwards.

## 8.5.4 Propulsion

When rotating the command button clockwise propulsion power is increased.



- Battery voltages (12 V / HV)
- RPM
- Power delivered by batteries
- State of Charge of HV batteries
- Maximum cell temperature in HV battery
- Motor temperature
- Controller temperature

Figure 8-6 Propulsion screen

The desired power can be adjusted in the propulsion mode as follows:

- Clockwise rotation– increase power
- Anti-clockwise rotation – decrease power

When the power is set to 0 kW, the Extended Mode is entered and the propeller aligned vertically.

The pylon retraction mode is activated when the EXT/RETR switch is pushed downwards.

**NOTE:** The power displayed on the DCU always represents battery power. Since shaft power is lower than the indicated value and cannot be influenced by the pilot, all references to "power" in this document are understood to mean battery power, unless explicitly stated otherwise as shaft power.

### 8.5.5 12 V Battery charging

The HV batteries can be used to charge the 12 V control supply battery via a built-in DC-DC converter.

The following picture illustrates that 12 V charging is in progress.




Figure 8-7 Battery charging screen

- Charging is activated by entering the System Screen and setting Charge Supply Voltage to ON. The System screen When pushing the command button during boot-up or operation mode, the display cycles through the screens.
- It is also possible to activate the HV batteries and enable charging by pushing the EXT/RETR switch downwards whilst in Standby mode.

**NOTE:** The DC-DC converter can provide a maximum of 8 A. The 12 V supply batteries can be charged at approximately 3 A.

## 8.6 Other Information screens

When pushing the command button during boot-up or operation mode, the display cycles through the screens as follows:




Figure 8-8 Other information screens

### 8.6.1 Message Screen

Errors/warnings cautions and information messages are stored by the DCU and can be viewed by the pilot in the message screen.


Messages		
Date	Time	
23.01.2021	14:35	Precharge
23.01.2021	14:35	Motor Stop
23.01.2021	14:35	Motor Start
23.01.2021	14:35	One Battery
1.12.2020	14:35	Charge Stop
1.12.2020	14:35	Balancing
1.12.2020	14:35	Charge Start
12.09.2020	14:55	Motor Stop
12.09.2020	14:50	Battery Hold
12.09.2020	14:42	MC: MOTC
12.09.2020	14:40	MC: MOTC
12.09.2020	14:35	Motor Start

To see the detail of a specific listed message:

- Select "Detail" using the command button
- Scroll to the selected message
- Select message
- Observe detail by rotating command button to the right

Figure 8-9 Message screen

## 8.6.2 System Screen



The system screen has the following functionality:

- Enable/disable charging of the 12 V supply battery from the HV batteries
- Provide information from the insulation monitor and system voltages
- Calibrate the pylon actuator travel (see Maintenance Manual for more detail)


Figure 8-10 System screen

**NOTE:** When the message or service screen is shown, the monitoring of the motor operation is running in the background.

## 8.7 Warning Caution and Information messages

All **warning/error, caution, or information** messages are stored by the DCU. Messages are prioritized and colored as follows:

Message type	Background color	Audio warning
Warnings	RED	Loud repeated beep until acknowledged
Cautions	YELLOW	1-second beep
Information	WHITE	½ second beep



Warning/Caution/Info messages cover the lower part of the screen

- A small triangle in the top right corner will be displayed as a reminder that a message exists. The triangle has the same as the original message
- A message is acknowledged by pressing the command button

Figure 8-11 Warning screen

**CAUTION:** If an operation limit is exceeded, the pilot is required to take the required action. Only limited automatic system control is implemented to protect the RES if used outside its design limitations.


**NOTE:** Only the unacknowledged message with the highest priority will be displayed.

A list of messages is provided in APPENDIX D – LIST OF WARNINGS/CAUTIONS.

## 8.8 Maintenance mode

Enter maintenance mode (or service mode) by pushing and holding the command button on the DCU while switching the RES master switch to ON.

Whilst in the Service Screen it is still possible to control the pylon extending / retraction using the “EXT/RETR” switch.



**NOTE:** The spindle movement is monitored by the DCU and the calculated pylon position is stored by the DCU when the system is shut down. Retraction errors may indicate that the system has to be re-calibrated.

Current drawn by the spindle is shown as well as the identified status of the retraction mechanism.

Figure 8-12 Service screen

## 8.9 Setup menu

The setup menu is accessed from the maintenance mode. When in maintenance mode, move from the general tab to the Access tab and enter the DCU password.



Figure 8-13 Setup screen

## 8.10 Charge mode

If the HV battery charger is connected to the aircraft and switched on, the DCU will enter a charging mode. Refer to the High Voltage batteries section.

## 8.11 Fire warning system

The fire warning system is independent of the RES system. It consists of two thermal switches, a heat-sensitive cable section located in the rear fuselage compartment, a 9 V battery, test button, LED, and buzzer.

The fire warning system can be tested by pressing the test button. When the test button is pressed, the system buzzer will sound and the indication LED will light up. If the 9 V battery is drained, the system will not work.



No	Description	No	Description
1	Test button	2	LED

Figure 8-14 Fire warning system

**WARNING:** The 9 V battery must be replaced every two years (as part of the documented maintenance) or any time it fails a pre-flight test - whichever occurs sooner.

## 9 SOFTWARE/ FIRMWARE UPDATE

The RES allows for the updating of the RFU and DCU. The parameters of the motor controller can also be adjusted. The required cables to perform the updates can be ordered from Jonker Sailplanes.

**NOTE:** Only firmware updates that are approved and officially released by SOLO® Vertriebs- und Entwicklungs GmbH.

### 9.1 Requirements for firmware updated

For the update of the DCU and RFU firmware, the following is required:

- PC with Windows and a USB port
- USB cables required:
  - DCU - USB cable Type A/B
  - RFU - USB cable type A/miniB
- Download and install the software provided by the link below:  
<https://www.flashmagictool.com/download.html&d=13.31/FlashMagic.exe>
- Firmware required provided by SOLO
  - Project file (file suffix: fmx)
  - New firmware file (file suffix: hex)

## 9.2 DCU firmware update

DCU firmware is updated as follows:

1. Connect the computer and the DCU with the USB-cable
2. Open the flashMagic.exe software
3. File/Open Project and select "FlashMagic\_DCU.fmx"
4. Switch on the RES main switch and observe the new COMM port displayed.
5. Perform the following configuration:

**Device:**

Device: LPC1788

Serial Port: Select the new COM-port that appeared after the RES was switched ON.

Baud rate: 57600 Baud

**Erase:**

Erase: Select "Entire Device"

**Firmware:**

File: Select the hex-file with the new firmware.

**Options:** - Verify after programming  
- Go after Programming

6. Click the big button below **Start** to initiate the flashing process

**NOTE:** It takes up to 10 seconds before information in the footer of the flash magic window displays the memory address being updated. The initial count-down during programming is followed by a count-up during the verification process.

7. Reset the main switch after the message "Finished" is displayed in the footer

### 9.3 RFU firmware update

RFU firmware is updated as follows:

1. Connect the computer and the RFU with the USB-mini B cable.
2. Open the flashMagic.exe software.
3. File/Open Project and select "FlashMagic\_RFU.fmx".
4. Switch on the RES main switch and observe the new COMM port displayed.
5. Perform the following configuration:

**Device:**

Device: LPC11C24/301 (LPC1000)

Serial Port: Select the new COM-port that appeared after the RES was switched ON.

Baud rate: 57600 Baud

**Erase:**

Erase: Select "Entire Device"

**Firmware:**

File: Select the hex file with the new firmware.

**Options:**

- Verify after programming
- Go after Programming
- Patch Before Programming: click on "Settings..." and add a new line with Address = 0x7FFE and "Bytes" equals the serial number as a 16-bit integer in "Little Endian" format.

6. Click the big button below **Start** to initiate the flashing process.

**NOTE:** It takes up to 10 seconds before information in the footer of the flash magic window displays the memory address being updated. The initial count-down during programming is followed by a count-up during the verification process.


7. Reset the main switch after the message "Finished" is displayed in the footer.

## 9.4 Accessing the motor controller parameters

The motor controller needs to be switched on to access it using the N-drive software. This can be done by switching on the system normally or by using the Maintenance mode.

**WARNING:** Connecting to the motor controller using N-drive could cause the propeller to start rotating during connection for a short period. Be sure to always be clear of the propeller.

1. Switch off the RES main switch.
2. Install both HV batteries.
3. Disconnect the 15 pin D-sub of the motor controller.
4. Connect the adapter to the motor controller and wiring loom of the aircraft:



**Figure 9-1 Adapter installation**

5. Connect a PC to the adapter using an RS232 to USB cable.
6. Boot the DCU into Maintenance mode.
7. Fully extend the pylon to ensure the propeller clears the front and main doors.
8. Access the setup menu.
9. In the setup menu, scroll to the MotorCtl tab.
10. Move to the command field and enter it.
11. In the command field scroll unit "Motor controller setup" is displayed.
12. Enter this command, the field will change to red. The motor controller will switch on
13. Connect to the motor controller using the N-drive software.

**NOTE:** The NDrive software can be downloaded from the following link:  
<https://www.unitek-industrie-elektronik.de/images/downloads/NDrive/NDrive2-Software.zip>.


## 10 High Voltage batteries

The Emetric BM384 battery system consists of 384 cells per battery which have a total nominal voltage of 350 V, total nominal capacity of 11.2 Ah, and maximum usable energy of 4.2 kWh. Batteries are sealed to minimize the risk of a battery fire. The type of Li-Ion cells used in the batteries is sensitive to excessive heat and may spontaneously ignite at temperatures above 150°C. Cell life is also reduced with high temperatures. Operation above 60 °C should be avoided. The battery pack is designed to prevent the propagation of fire in a single cell. When a cell ignites, approximately 12 l of high temperature, poisonous gasses will be released instantaneously. These gasses are directed via the exhaust nozzle to the outside of the aircraft. Battery requires no internal maintenance.

**WARNING:** Do not inhale any gasses as the result of a battery fire.

**WARNING:** Battery maintenance must be done by the supplier or OEM.

### 10.1 Overview



No	Description	No	Description
1	Handle	2	Battery status indicators
3	Connector	4	Alignment pin
5	Exhaust vent	6	Battery latch

Figure 10-1 Battery overview

## 10.2 Inspections

The following inspections should be performed regularly – typically before installing the batteries into the fuselage:


1. Verify the lifting handles on top of each battery are securely attached to the hard-shell case with no indication of detaching or signs of loose fasteners.
2. Verify the latch plate at the rear of each battery is firmly attached to the hard-shell case and that its fasteners are secure.
3. Visually inspect the multi-pin connector at the front of the shell for any sign of contact pin damage or debris. Clean with filtered compressed air and/or contact cleaner spray. Additionally, inspect the fasteners that secure the connector to the shell.
4. Verify the locator guide pin at the front of the shell is without any play and rigidly attached to the case.
5. Verify the integrity of the exhaust port sleeve at the lower front region of the shell.
6. Visually check that the low-profile fasteners around the edge of the shell are secure.
7. Inspect the entire shell (especially the bottom sliding surface and the corners) for any indication of wear, cracks, or puncturing through the walls.

## 10.3 Trailer considerations

Batteries have a mass of 50 kg (110 lbs) for the pair. Their placement in the trailer (if stored outside the fuselage) can therefore affect the CG of the trailer noticeably. The trailer behavior on roads and motorways can easily be made unstable rendering the towing vehicle unsafe to drive.

## 10.4 Battery status indicators

The high voltage status indicators are located on top of the battery close to the high voltage connector.



No	Description	No	Description
1	High voltage indicator	2	Status Indicator

Figure 10-2 Battery status indicators

### 10.4.1 High voltage indicator

The high voltage indicator only lights up when the battery is connected to the aircraft or charger. The high voltage indicator lights up when the high voltage pins are activated. When the battery is switched off, it can take up to 10 seconds for the high voltage to dissipate.

**WARNING:** The battery should never be handled if this indicator is on.

### 10.4.2 Status indicator

The status indicator only lights up when the battery is connected to the aircraft or charger. The individual lights indicate the state of charge (SOC) of the battery. Each individual light corresponds to 10% capacity, if four bars are lit – the battery has a 40% state of charge.

**CAUTION:** An error is indicated when all of the bars light up and start to flash in approximately 1-second intervals.

## 10.5 Battery handling

The batteries should only be carried by using both handles.

**WARNING:** The connector should be treated as if it is always live – do not touch the connector.

The batteries should be left inside the fuselage or transported in suitable safe transport containers.


**WARNING:** HV batteries are sensitive to ground handling. Exposure to high G-loadings or mishandling must be avoided, as this may lead to battery failures or fires and the void of warranty.

## 10.6 Installing the HV batteries

1. Select the 12 V battery to power the RES system.
2. Enter maintenance mode by pushing and holding the command button on the DCU while switching the RES master switch to ON.
3. Whilst in maintenance mode the motor can be extracted by pushing the EXT/RETR switch upwards.


**CAUTION:** When the HV system is not activated the propeller alignment function is inactive. Take care that the propeller is aligned when extending the pylon to avoid damage to the propeller or doors.

4. Switch the RES master switch OFF.
5. Insert the batteries in the battery compartment and slide forward into the secured position.
6. Secure batteries with latch and fastening of the thumb screw.
7. Insert or ensure that a terminal connector is inserted in the charge connector, as illustrated in Figure 10-3.
8. Switch the RES master switch ON.
9. Test operation.
10. Retract pylon by pushing the EXT/RET switch downwards



**Figure 10-3 Dual battery operation**

If a single battery is installed in the fuselage, the terminal plug must be inserted in the fuselage side connector of the 2<sup>nd</sup> battery, as illustrated in Figure 10-4.



**Figure 10-4 Single battery operation**

## 10.7 Battery care

Batteries should be treated with care to get the designed performance from the battery. The cell manufacturer guarantees 300 charge/discharge cycles provided that good care is taken.

- Do not discharge the cells below 2.5 V per cell
- Do not expose the cells to high temperatures
- High rates of discharge shorten the life of the cell
- Do not store batteries fully charged or empty.
- Do not charge the batteries too fast
- Comply with long term storage specifications

## 10.8 Long term storage

It is recommended to remove RES batteries and store them in a dry place with the following conditions:

**State of Charge:** 35-50%

**Temperature:** 10-23 °C

**Humidity:** <75%

It is recommended to verify the state of the batteries every 3 months to ensure that the batteries do not go into a state of discharge. If the state of charge is less than 20-30%, top up the batteries with an adequate amount of charge.


**NOTE:** The winter charging mode can be used to achieve the acceptable SOC for storage.

## 10.9 Charging

### 10.9.1 In aircraft charging

The HV batteries can be charged at own risk inside the aircraft using the following process:

1. Remove the terminal plug and connect the charger plug to the charge port in the fuselage.
2. Insert a terminal connector to Cable B of the battery charger.
3. Turn charger ON.
4. Within 20 sec after the charging process is initiated, the DCU offers two additional charge options:
  - Limiting the charging power; or
  - Switching to winter charging




**Figure 10-5 Dual battery in aircraft charging**

Once the charger is connected, 12 V power is supplied to the battery manager, IMD, and DCU. The battery manager starts the charging process by activating the HV relays with the DCU monitoring the process.

Once batteries are fully charged the battery manager switches off the charging process and the DCU displays the standby screen.

If a single battery is charged inside the fuselage, the terminal plug must be inserted in the male connector of the removed battery, as illustrated in Figure 10-6.




**Figure 10-6 Single battery in aircraft charging**

### 10.9.2 External charging

The HV batteries should be charged under supervision or where the risk of a battery fire will cause minimum damage to the surroundings.

1. Remove the HV batteries from the fuselage.
2. Connect the charger plug to the batteries.
3. Turn charger ON. If the toggle switch is operated while the charger is switched on, the winter charging mode is activated.




**Figure 10-7 External dual battery charging**

Once the charger is connected 12 V power is supplied to the battery manager. The battery manager starts the charging process by activating the HV relays.

When batteries are fully charged the battery manager switches off the charging process.

If a single battery is charged outside the fuselage, the terminal plug must be inserted in the connector of Cable B of the battery charger, as illustrated in Figure 10-8.



**Figure 10-8 External single battery charging**

**NOTE:** Batteries should be charged at temperatures between 23 °C and 45 °C (73 °F and 113 °F). Charging at lower temperatures will result in batteries not being charged to the maximum capacity (cell temperatures of 0 °C can be charged to 85% of their available capacity).

*Intentionally left blank*

## **11 PLACARD BOOKLET**

The RES has a placard booklet which can be found in the cockpit of the aircraft. Ensure the Placard booklet and the latest approved Aircraft Maintenance Manual has the same revision. The complete Placard Booklet is provided in the Aircraft Maintenance Manual.

*Intentionally left blank*



*Intentionally left blank*

## **14 Contact**

### **14.1 Type Certificate Holder**

#### **M&D Flugzeugbau GmbH & Co. KG**

Streeker Straße 5b

26446 Friedeburg

Germany

☎ +49 (0) 4465 / 97878 – 11

Mail: [info@md-flugzeugbau.de](mailto:info@md-flugzeugbau.de)

### **14.2 Manufacturer / Maintenance**

#### **M&D Flugzeugbau GmbH & Co. KG**

Streeker Straße 5b

26446 Friedeburg

Germany

☎ +49 (0) 4465 / 97878 – 11

Mail: [info@md-flugzeugbau.de](mailto:info@md-flugzeugbau.de)

*Intentionally left blank*

## APPENDIX A – ANNUAL INSPECTION CHECKLIST

<b>JS-MD 3</b>	<b>SIGN</b>	<b>SIGN</b>
<b>ANNUAL (OR 100 HOUR MOTOR OPERATION) INSPECTION CHECKLIST</b>	<b>action completed</b>	<b>checked</b>
<b>Pylon</b>		
Inspect pylon for play at its base when extended		
Inspect high voltage cables at pylon base for damage		
Inspect pylon base bolts and Brackets		
<b>Motor</b>		
Inspect Motor connection bolts		
Inspect high voltage motor connectors for damage		
Inspect All wiring for damage		
<b>Propeller</b>		
Inspect propeller bolts and locking wire		
Inspect propeller for cracks and chips		
<b>Pylon Retraction/Extension mechanism</b>		
Inspect all Bolts on Retraction/Extension Mechanism		
Inspect linear actuator wiring and connector for damage		
<b>Main doors</b>		
Inspect door edge clearance with fuselage (Doors should not catch on recess)		

<p style="text-align: center;"><b>JS-MD 3</b></p> <p style="text-align: center;"><b>ANNUAL (OR 100 HOUR MOTOR OPERATION)</b></p> <p style="text-align: center;"><b>INSPECTION CHECKLIST</b></p>	<p style="text-align: center;"><b>SIGN</b> action completed</p>	<p style="text-align: center;"><b>SIGN</b> checked</p>
Inspect door driver rod ends for damage (Lubricate)		
Inspect door BC springs and lug for damage		
Inspect door BC stop for damage (Doors should not touch Fuselage when open)		
Inspect door BC cable and crimps for damage		
<b>Battery latches</b>		
Inspect battery latch brackets and latch for damage		
Inspect battery latch bolt		
<b>High voltage batteries</b>		
Inspect battery latch plate for damage		
Inspect battery connectors for damage		
Inspect battery box for external damage		
<b>Battery connector bracket</b>		
Inspect cover for damage		
Inspect high voltage connectors for damage		
Inspect wiring entering connector bracket for damage		
<b>Air cooled controller cooling fan assembly</b>		
Inspect fan bolts		

<p style="text-align: center;"><b>JS-MD 3</b></p> <p style="text-align: center;"><b>ANNUAL (OR 100 HOUR MOTOR OPERATION)</b></p> <p style="text-align: center;"><b>INSPECTION CHECKLIST</b></p>	<p style="text-align: center;"><b>SIGN</b> action completed</p>	<p style="text-align: center;"><b>SIGN</b> checked</p>
Clean fans and fan finger guards		
Inspect wiring loom for damage on both sides where it passes through the fan plate		
<b>Air cooled controller (if fitted)</b>		
Inspect all Controller box fastening bolts		
Inspect high voltage cables for damage where they pass through the box		
Inspect Motor controller data connectors for damage		
<b>Liquid cooled controller (if fitted)</b>		
Inspect all Controller box fastening bolts		
Inspect high voltage cables for damage where they pass through the box.		
Inspect Motor controller data connectors for damage		
Inspect piping and radiator for water leakages.		
Inspect security of radiator, fan and water pump assembly		
Inspect coolant level (section 4.11.2.4.5)		
<b>RFU- IMD assembly</b>		
Inspect connectors to RFU and IMD for damage		
<b>Seatback Battery</b>		
Inspect the battery housing and wires for any damage		

<p style="text-align: center;"><b>JS-MD 3</b></p> <p style="text-align: center;"><b>ANNUAL (OR 100 HOUR MOTOR OPERATION)</b></p> <p style="text-align: center;"><b>INSPECTION CHECKLIST</b></p>	SIGN action completed	SIGN checked
Inspect the battery for any swelling or deformation		
<b>Seatpan Battery</b>		
Inspect the battery housing and wires for any damage		
Inspect the battery for any swelling or deformation		
<b>Fire warning system</b>		
Functional check of fire warning system and replace battery		

## APPENDIX B – GENERAL TORQUE SPECIFICATIONS

The following torque specifications can be used as a guideline during maintenance of the various components unless specified otherwise:

Thread	Torque specification [Nm] - Dry
M4	3
M5	4.5
M6	10
M8	20

*Intentionally left blank*



*Intentionally left blank*

## APPENDIX D – LIST OF WARNINGS/CAUTIONS

The following table shows the priority of the messages.

WARNINGS / ERRORS	
Propeller overspeed !!! Reduce Power"	Reduce torque setting or airspeed.
Interlock Circuit not closed!!! Check Connectors	During system startup the interlock circuit is not closed. Check connectors to batteries and charge port (if installed)
Power Setting Defect !!!	Signal from torque setting not valid. Maybe a broken wire or defect mechanics. Maintenance necessary.
Battery DRAINED No Motor Power Connect Charger! All Batteries empty	lowest cell voltage is < 2.5 V. No motor operation possible. Connect charger as soon as possible  Remaining motor operation time < 2 min
Supply Voltage too high Shut-off main switch!	Voltage exceeds 15,0 V. Wrong battery type used or voltage control inside DC-DC converter is not adapted or damaged.
No Data from Charger  No Data from Isometer	No CAN-Bus messages from charger.  No CAN-Bus messages from eFlightBox where the isometer is integrated.
Isometer defect!	Self-test of isometer not successful. No measurement of the insulation between LV circuit and HV circuit will be performed. Potential insulation problems cannot be detected and therefore danger of electric shock.
Isometer Wiring Failure!	Isometer detected a bad connection between 0 V and ground, between the isometer and + HV-rail or isometer and -HV rail. No measurements can be performed and therefore danger of electric shock.
Insulation Problem!!! Turn Main Switch Off Maintenance	Insulation result is lower than 500kΩ. This is too low. Danger of electric shock.
No Data from RFU!	No CAN messages from RFU. Do not use the system and check wiring between DCU and RFU. If this issue happens sporadically, check CAN-Bus wires and shielding.
No Data from Motor Controller! Press CMD to stop motor	No CAN messages from Motor Controller. If the motor is running it continues until command button is pressed. Do not use the system and check wiring between DCU and eControl. If this issue happens sporadically, check CAN-Bus wires and shielding.

No Data from Battery A	No CAN messages from left battery. Do not use the system and check wiring between Battery A and DCU. If this issue happens sporadically, check CAN-Bus wires and shielding.
No Data from Battery B	No CAN messages from right battery. Do not use the system and check wiring between Battery B and DCU. If this issue happens sporadically, check CAN bus wires and shielding.
Watchdog Reset!	Detected error in software. DCU restarted automatically.
No Communication!	CAN-Bus Fault. Check wiring.
Supply Voltage too low! Start recharging supply voltage battery!	Supply voltage is below 10,0 V. Switch on recharging process.
Coolant Pump Failure Stop Motor as soon as possible! Press CMD to Resume	Coolant pump is switched on but no tacho signal is received by the RFU. Terminate motor operation as soon as possible. eControl may be damaged by over temperature.
Invalid firmware version	The firmware of one device of the propulsion system does not provide the correct firmware version. After message is acknowledged you can read the last entry in the boot window. It represents the device with the wrong firmware version.
Retraction Mechanism Current overload Wait and try again	The self-resetting fuse of the spindle motor has blown. It cools down in a few seconds then you can try again using the retraction switch.
Retraction Mechanism Error Use emergency retracting switch	Limiting switches at the extended and retracted position of the retraction mechanism show an invalid status. e.g. Both limit switches are open.
Retraction Mechanism Timeout! Spindle blocked?	Spindle was powered longer than OEM-adjustable limit. Operate spindle using emergency operation mechanism and watch propeller
Precharge Timeout! Service Disconnect?	The voltage level at the eControl and the batteries do not level in between 1,5sec. Switch off system and restart.
<b>Warning / Error messages from eControl</b>	
MC: BAD PARAMETER	Possible causes: <ul style="list-style-type: none"> <li>• Damaged parameter setting</li> <li>• Firmware not valid for the system or firmware damaged</li> </ul> Contact manufacturer
MC: POWER FAULT	Overall message of hardware monitoring. Possible causes may be: <ul style="list-style-type: none"> <li>• Overvoltage across the bus circuit</li> <li>• Driver card voltage monitoring (15 V, 5 V)</li> </ul>

	<ul style="list-style-type: none"> <li>• Undervoltage monitoring of the supply voltage (&lt; 10 V)</li> <li>• Overtemperature in at least one IGBT module</li> <li>• Dangerous overcurrent (causes may be currents which are too high or oscillating currents, bad controller adjustments, or hardware defects (e.g. IGBT module))</li> </ul>
MC: RFE FAULT	Safety circuit faulty (only active with RUN-signal)
MC: BUS TIMEOUT	CAN-Bus timeout
MC: FEEDBACK	Resolver signal faulty or missing
MC: POWER VOLTAGE	Power voltage missing
MC: MOTOR TEMP 1 Reduce Power Instantly!	Motor temperature too high (> 120 °C) Attention, if occurs in flight: Proceed flight, eventually broken sensor wire. Attention, if occurs after maintenance or on ground: switch off the system immediately, possible overspeed of motor within seconds.
MC: DEVICE TEMP Power Reduced	Device temperature too high (> 80°C)
MC: OVERVOLTAGE	Overvoltage (power voltage)
MC: I_PEAK	Overcurrent or strongly oscillating current detected. This error is also often triggered if the power supply has low voltage spikes.
MC: RACEAWAY	Drive races (without command value, wrong direction)
MC: I Sensor	Current measurement error
MC: BALLAST	Ballast circuit overloaded
<b>Warning / Error messages from the batteries</b> <u>Messages shown are for BATTERY A. Each message also exist for BATTERY B!</u>	
BATTERY A: Modul Timeout Discharge Only Maintenance!	Error during self-test. Discharge only. Maintenance necessary.
BATTERY A: Cell Connection Discharge Only Maintenance!	Error during self-test. Discharge only. Maintenance necessary.
BATTERY A: Temperature Reg. Discharge Only	Error during self-test. Discharge only. Maintenance necessary.

Maintenance!	
BATTERY A: Cell Voltage Reg. Discharge Only Maintenance!	Error during self-test. Discharge only. Maintenance necessary.
BATTERY A: No Module Data Discharge Only Maintenance!	Error during self-test. Discharge only. Maintenance necessary.
BATTERY A: Battery TOO HOT Stop Motor !!!	Battery > 70°C.
BATTERY A: Battery Empty !!! Stop Motor !!!	SOC < 3%
BATTERY A: Off! Precharge Error Check wiring and try again!	Only when charger is connected: Batman tries to pre-charge the power bus, but charger shows no voltage data.
BATTERY A: Off! Cell Overvoltage Reset Power Maintenance	Can only happen if charger is connected. Maintenance may be necessary
BATTERY A: Cell voltage difference. Maintenance Required	The battery cell voltage difference is higher than 50mV during boot time and the maximum cell voltage is higher than 4,0 V. Motor can be used after confirming the message.
BATTERY A: Off! Charger Error Check Wiring	Can only happen if charger is connected. Reasons may be: <ul style="list-style-type: none"> <li>• Communication problem between both batteries</li> <li>• One battery is connected after power on.</li> </ul>
BATTERY A: Off! Cell Overvoltage New Precharge. Maintenance	At least one battery cell is higher than 4,2 V. Reset by a new pre-charge after problem is solved.

BATTERY A: Off! Cell Drained Connect Charger!	At least one battery cell voltage is below 2,3 V. It is possible to reset this state by a new pre-charge event.
BATTERY A: Off! -Overcurrent- Reset Power	Hardware shutoff due to high current. Reset by power cycle.
BATTERY A: Off! -Permanent Shutoff- Maintenance Required  BATTERY A: Off! Critical Overtemperature Possible Fire! Maintenance	At least one battery cell voltage is < 2,0 V. Battery is permanently shut off. Reset only by maintenance personal.  Battery temperature > 85°C. Battery is permanently shut off. Reset only by maintenance personal.
BATTERY A: Current too high Decrease power setting immediately!	Battery current > 80 A. Maybe only one battery is connected to the power bus. Probably only one battery is connected unintentionally. Connect only one battery and check which one is working. Maintenance necessary.
<b>Warning / Error messages from the charger</b>	
CHARGER: Hardware Error Remove Charger and try again	General hardware error. Can only be cleared by power reset.
CHARGER: Overtemperature	Charger too hot. Switch charger off until it cools down.
CHARGER: No Battery  CHARGER: Communication Timeout	Charger cannot detect valid battery voltage.  Charger didn't receive control message for five seconds.
<b>CAUTIONS</b>	
CAN Buffer full	This message shouldn't show up in a system with correct parameter setup

<p>One Battery disconnected NO TAKE-OFF !!!</p> <p>Battery charge too low. NO TAKE-OFF !!!</p> <p>Insulation Resistance low. Check Insulation!</p>	<p>One battery operation. Motor torque is limited to 50%</p> <p>Battery charge level is too low for a take-off followed by a 5- minute climb.</p> <p>Insulation result is lower than 2000kΩ. This is low. Further decrease may lead to the danger of electric shock.</p>
<p>Supply Voltage Low. Recharge supply voltage battery</p>	<p>Supply voltage below 10,5 V</p>
<p>Motor Current Limit! Propeller speed high</p>	<p>Motor controller limits power to the motor. This message shouldn't show up in a system with correct parameter setup</p>
<p>Motor Current Limit! Motor temperature</p>	<p>Motor controller limits power to the motor. This message shouldn't show up in a system with correct parameter setup</p>
<p>Motor Current Limit! Temperature Motor Controller</p>	<p>Motor controller limits power to the motor. This message shouldn't show up in a system with correct parameter setup</p>
<p>Remove Charger !</p>	<p>If in standby motor operation is demanded but the charger is still connected.</p>
<p>Battery Cell voltage low Motor LIMITED !</p>	<p>At least one battery cell voltage is at a low level.</p>
<p>Battery voltage difference too high NO TAKE-OFF !!!!</p>	<p>Battery voltage difference is &gt; 30 V. Battery with lower voltage is disabled, so no take-off is possible.</p>
<p>All Batteries low !</p>	<p>Remaining motor operation time &lt; 5 minutes.</p>
<p>Insulation measuring results bad. Maintenance</p>	<p>Insulation measuring process is disturbed. Possible causes are too much ripple on the HV-rail. If problem persists, get in contact with manufacturer.</p>
<p>Battery B not Connected</p>	<p>DCU does not get any data from Battery B. During operation the battery may get disconnected at any time. At start up battery will stay unconnected.</p>

Battery A not Connected	DCU does not get any data from Battery A. During operation the battery may get disconnected at any time. At start up battery will stay unconnected.
Interlock Warning! Battery or Charger not Connected!	Connectors to batteries, charger or dummy plugs are not fully locked and may fall off at any time.
Retraction Mechanism Pylon angle invalid. Watch Pylon angle.	The limiting switch for the extended position is triggered, but the pylon angle value is too low. Possible causes may be: <ul style="list-style-type: none"> <li>• angle for fully extended pylon not set correctly</li> <li>• damaged limit switch</li> <li>• damaged angle detection system.</li> </ul> See maintenance manual for further steps to adapt the angle detection system to the installation.
Retraction Mechanism Current too high. Maintenance	Current to spindle exceeds OEM-adjustable limit for 3 seconds. Possible cause may be: <ul style="list-style-type: none"> <li>• stiff mechanics</li> <li>• worn or blocked spindle motor</li> </ul>
Retraction Mechanism Emergency Operation Watch Propeller	Emergency or Maintenance Retraction switch was triggered. The spindle moves without control by the DCU.
<b>Caution messages from eControl:</b>	
MC: Device detection inconsistent	Device detection is inconsistent. Maintenance
MC: ILLEGAL STATUS	RUN signal disturbed, EMI Maintenance
MC: SAFE_IN	RFE Input not active while RUN is not active) Maintenance
MC: MOTOR TEMP Reduce Power!	Motor temperature high (> 105 °C)
MC: DEVICE TEMP Reduce Power!	Device temperature high (> 75 °C)
MC: insufficient Battery Power	Battery voltage too low to set the motor current that is rated.
MC: I_PEAK	Overcurrent 200%
MC: RACEWAY	Resolution range of the speed measurement reached
MC: 2.Supply Fail	Second 12V supply voltage missing

MC: Secondary Feedback Fail	Secondary resolver signal faulty or missing. Primary resolver signal active.
MC: BALLAST	Ballast circuit > 87 % overloaded
<b>Caution messages from the Batteries:</b> <i>Messages shown are for BATTERY A. Each message also exists for BATTERY B</i>	
BATTERY A: Battery Hot !	Maximum battery cell temperature > 60 °C
BATTERY A: Battery Low !	SOC < 10%