



## Technical Note TN.JS-007

04 April 2012

### TITLE

Retrofit of parachute static line.

### DESCRIPTION

Retrofit of the parachute static line.

### INSTRUCTIONS

1. Drill an 8mm hole through B5 at location illustrated in image below.



Figure 1: Position of hole through B5

2. Use an 8mm to 16mm counter-bore tool to create a flat landing for the ring to seat properly as shown in figure below.




Figure 2: Flat landing for ring seat

3. Test fit static line ring and cut bolt shorter if necessary to save weight
4. Remove ring and sign in to travel kit

### MATERIAL SUPPLIED/REQUIRED

DRAWING D1A-1.03.82

PARTS: 1A-1.03.82

### TOOLS REQUIRED

Hand drill

8mm drill bit

8-16mm counter-bore tool

### MASS AND BALANCE/MANUALS

No change to mass or balance or Flight Manual and Maintenance Manual.

### NOTES

This Technical Note must be completed by an approved maintenance person.

